

Preliminary 21<sup>st</sup> of May, 2015

*Torque, Linear and Custom Motors*

*Stepper, Servo and Traction Motors*

*Drive Electronics and Controllers*

*Actuators and Sensors*

*CAE Tools and Engineering*

*Motion Control Systems*

## **SINE WAVE COMMUTATED SERVO MODULE**

*SWM7S – standard version and SWM7 – 300/600*



### *User Manual*

<i>Introduction</i>	<i>1</i>
<i>Handling and Package</i>	<i>2</i>
<i>Technical Description</i>	<i>3</i>
<i>Mechanical Installation</i>	<i>4</i>
<i>Electrical Installation</i>	<i>5</i>
<i>SetUp Tool SWM7</i>	<i>6</i>
<i>Operation</i>	<i>7</i>
<i>Glossary</i>	<i>8</i>
<i>Index</i>	<i>9</i>
<i>EMC Consideration</i>	<i>10</i>

This handbook is the copyright of MACCON GmbH, Munich. No part may be reproduced or otherwise disclosed to third parties without written permission.

The content of this documentation has been worked out and thoroughly investigated by personnel of MACCON.

Every possible effort has been taken during the preparation of this handbook to avoid errors. However should the user recognize mistakes or wish to recommend improvements, MACCON will be grateful for such information.

MACCON also reserves the right to make any corrections to this handbook without prior notification.

MACCON is not deemed liable for any damage incurring through the application of the SWM7 series of brushless servo drives or this handbook be it through infringement of patents or rights of others or otherwise.

Some technical terms used in this documentation are registered trade marks. With this, they are liable to legal conditions.

Copyright © MACCON GmbH 2015. All rights reserved.

Issued by

**MACCON GmbH**  
**Aschauer Str. 21**  
**D-81549 München**



Only qualified personnel are permitted to perform activities such as transportation, installation, commissioning and maintenance. Qualified personnel are persons who are familiar with the transport, assembly, installation, commissioning and operation of the product and to their job have the qualifications.

The qualified personnel must know the following standards and guidelines and note:

- IEC 364 bzw. CENELEC HD 384 or DIN VDE 0100
- IEC-Report 664 or DIN VDE 0110
- National accident prevention regulations or VBG 4.

Read before installing and commissioning the present documentation. Incorrect operation of the servo amplifier can lead to personal injury or property damage. Observe the technical data and information on connection requirements (nameplate and documentation)!



The servo controller contains electrostatically sensitive components which can be damaged by improper handling. Discharge your body before touching the servo amplifier. Avoid contact with highly insulating materials (artificial fabrics, plastic films etc.). Place the servo amplifier on a conductive surface.

During operation, servo amplifiers to their protection can have live, bare parts. Control and lead terminals may be live even if the motor does not rotate.

During operation, servo amplifiers may have hot surfaces. Since the base plate is used as a cooling element, it may reach temperatures up to 85° C, i.e. 185° F.

Never undo any electrical connections to the servo amplifier while it is energized (switched-on). There is a danger of electrical arcing with damage to contacts and serious personal injury.

Wait at least eight minutes after disconnecting the servo amplifier from the main supply power before touching potentially live sections of the equipment (e.g. contacts) or undoing any connections.

Der Inhalt dieser Dokumentation wurde von Mitarbeitern der MACCON GmbH mit großer Sorgfalt erarbeitet und geprüft. MACCON übernimmt jedoch keine Verantwortung für Schäden, die aus Fehlern oder Fehlinterpretationen dieser Dokumentation resultieren können. Falls Sie Fehler bemerken oder Verbesserungen wünschen, so senden Sie diese bitte an MACCON.

MACCON hat das Recht, Änderungen an den beschriebenen Produkten oder an der Dokumentation ohne vorherige Ankündigung vorzunehmen, wenn sie aus Gründen der Zuverlässigkeit oder Qualitätssicherung vorgenommen werden oder dem technischen Fortschritt dienen.

Sämtliche Rechte an der Dokumentation liegen bei MACCON.

Die Weitergabe an Dritte und Vervielfältigung jeder Art, auch auszugsweise, sind nur mit schriftlicher Genehmigung durch MACCON gestattet. Ausgenommen sind Arbeitskopien, die ausschließlich eigenen Zwecken dienen.

Einige in dieser Dokumentation verwendeten technischen Bezeichnungen sind auch eingetragene Warenzeichen und unterliegen als solche den gesetzlichen Bestimmungen.

Copyright © MACCON GmbH 2015. Alle Rechte vorbehalten.

Herausgegeben von:

**MACCON GmbH**  
**Aschauer Str. 21**  
**D-81549 München**



Nur qualifiziertes Fachpersonal darf Arbeiten wie Transport, Installation, Inbetriebnahme und Instandhaltung ausführen. Qualifiziertes Fachpersonal sind Personen, die mit Transport, Aufstellung, Montage, Inbetriebnahme und Betrieb des Produktes vertraut sind und über die ihrer Tätigkeit entsprechenden Qualifikationen verfügen.  
Das Fachpersonal muß folgende Normen bzw. Richtlinien kennen und beachten:

- IEC 364 bzw. CENELEC HD 384 oder DIN VDE 0100
- IEC-Report 664 oder DIN VDE 0110
- Nationale Unfallverhütungsvorschriften oder VBG 4.

Lesen Sie vor der Installation und Inbetriebnahme die vorliegende Dokumentation. Eine falsche Bedienung des Servoverstärkers kann zu Personen- oder Sachschäden führen. Beachten Sie die technischen Daten und die Angaben zu den Anschlußbedingungen (Typenschild und Dokumentation)!



Die Servoverstärker enthalten elektrostatisch gefährdete Bauelemente, die durch unsachgemäße Behandlung beschädigt werden können. Entladen Sie Ihren Körper, bevor Sie den Servoverstärker berühren. Vermeiden Sie den Kontakt mit hochisolierenden Stoffen (Kunstfaser, Kunststofffolien etc.). Legen Sie den Servoverstärker auf eine leitfähige Unterlage.

Während des Betriebes können Servoverstärker ihrer Schutzart entsprechend spannungsführende, blanke Teile besitzen. Steuer- und Leitungsanschlüsse können Spannung führen, auch wenn sich der Motor nicht dreht.

Während des Betriebes können Servoverstärker heiße Oberflächen besitzen. Da die Grundplatte als Kühlelement verwendet wird, kann sie Temperaturen bis zu 85° C erreichen.

Lösen Sie die elektrischen Anschlüsse der Servoverstärker nie unter Spannung. In ungünstigen Fällen können Lichtbögen entstehen und Personen und Kontakte schädigen. Warten Sie nach dem Trennen oder Abschalten der Versorgungsspannungen der Servoverstärker, bis die internen Elkos entladen sind (mindestens 8 Minuten), bevor Sie spannungsführende Geräteteile berühren oder Anschlüsse lösen.

## Change History

### Reason for Update

#### Summary:

??

Improvement of existing description and support of new features.

**R05-15** issue of the document for this version of the product. This document contains 136 pages.

### Details for Document Revisions

Chapter	Reason for Update	
1	<a href="#">RFR</a>	[Review_sf]
2	<a href="#">RFR</a>	[Review_yr]
3 (old)	<a href="#">RFR</a> [check TBD in chap 3.1.3] DIN IEC 60529/A1:2010-04;  VDE 0470-1/A1:2010-04 <b>[Achtung: Dokument zurückgezogen 1]</b>  <b>[new chap. 3 – see file 3_Description_R01_issue 29th of April.pdf]</b>	[Review_km] [Review_yr]
4	<a href="#">RFR</a> [check TBD in chap. 4.4 Assembly ]	[Review_yr]
5	<a href="#">RFR</a> [check TBD in chap. 5.5.5 LWM7S ]	
6	<a href="#">RFR</a> gr. added runtime errors chap. 6.6.3.2 to 6.6.3.7  <b>Missing: Functional drawings for SWM7</b>	[Review_sf]
7 To Do:	<b>Start-up / Ongoing</b> – Capacitor reforming löschen → alle ? – Reglerstrukturen SWM7 Kap. 7.3.1.1 – ... good setup sequence (siehe unter Fig. 7.2) → gilt für SWM6 – Q und D nicht berücksichtigt → vor Kap. 7.3.2 – Anpassung an SWM7 erforderlich → Kap. 7.3.2.1 – welcher Link: englisch ? <a href="http://www.maccon.de/en/company/contact.html">http://www.maccon.de/en/company/contact.html</a>	[Review_sf]
8 GLO	<a href="#">RFR</a> Einträge <b>RFR</b> und <b>TBD</b> vor Freigabe löschenpacitor	
9 Index	Index updated/new format, added all "Control windows" for SWM7 14.02a	
10 EMC	<a href="#">RFR</a>	[Review_ak]

### Details for Hardware Revisions

Current Version of			Remarks
Hardware	Firmware	Software	
Rev. D4	tbd	SWM7 1212a	<b>SWM7 .EXE</b> file is running under Win2k, Windows XP, Vista, Windows 7 and Windows 8 → alle ?

### Issue History

Issue	Date of Issue	Reason for Update
MAC-SWM7-UMN-prel-R05-15	18.05.2015	<b>Preliminary and Start-up (Chap. 7.)</b>

## Table of Content

1	Introduction.....	13
1.1	About this manual.....	13
1.1.1	Target group.....	14
1.1.2	Structure of this manual.....	14
1.1.3	Related documentation.....	14
1.2	Restrictions.....	14
1.3	Safety Instructions.....	14
1.4	Typographical conventions.....	14
2	Handling and Package.....	17
2.1	Packaging, Transport and Storage.....	17
2.2	Maintenance and Cleaning.....	17
2.3	Disassembling.....	17
2.4	Repair Instructions.....	17
2.5	Disposal.....	18
2.6	Package .....	18
2.6.1	Package supplied.....	18
2.6.2	Nameplate for HW and SW.....	18
2.6.2.1	Hardware.....	18
2.6.2.2	Software .....	18
3	Technical Description .....	19
3.1	SWM7S family of digital servo controllers .....	19
3.1.1	Technical data.....	20
3.1.2	Fusing.....	21
3.1.3	Ambient conditions, ventilation and mounting position .....	22
3.1.4	Conductor cross-sections.....	22
3.1.5	Mechanical data .....	22
3.1.6	Grounding system .....	23
3.1.7	Switch-on and switch-off behavior .....	23
4	Mechanical Installation .....	25
4.1	Safety Instructions .....	25
4.2	Guide to mechanical installation.....	25
4.3	Dimensions .....	26
4.4	Assembly (TBD).....	26
4.4.1	Base plate 188 x 164 mm .....	27
4.4.2	Base plate 188 x 189 mm.....	28
4.4.3	SWM7 –300 V / –600 V wall mount version, high voltage.....	29
5	Electrical Installation .....	31
5.1	Safety Instructions .....	31
5.2	Guide to electrical installation.....	31
5.2.1	Sequence for installation:.....	32
5.3	Wiring .....	32
5.3.1	Safety Instructions .....	32
5.3.2	Connection diagrams.....	32
5.3.3	Shielding connection to the front panel .....	33
5.3.4	Motor connector X4 with shielding connection.....	33
5.3.5	Technical data for connecting cables.....	33
5.4	Connector assignments.....	34
5.5	Connection diagrams (Overview) .....	35
5.5.1	SWM7S-48/150.....	36
5.5.2	SWM7-48/150 with extended I/O .....	37
5.5.3	SWM7-48/100 (M6 motor connectors).....	38
5.5.4	SWM7S-300/600 .....	39
5.5.5	LWM7S (tbd).....	40
5.6	Power supply (X5).....	40
5.7	Temperature supervision (X3).....	40
5.8	Enable and command interface (X1), (X2) .....	41

5.9 Motor (DC1, DC3) and brake connection (X4), (X3)	41
5.10 Feedback	43
5.10.1 Hall sensors (X13)	43
5.10.2 Resolver (X9)	45
5.10.3 Encoder differential (X12)	46
5.10.4 Encoder unipolar (X12)	47
5.10.5 Sine Encoder with EnDat 2.2 (X11)	48
5.10.6 Netzer Encoder (X11)	49
5.10.7 DC Tacho	49
5.10.8 TTL Encoder (general)	49
5.10.8.1 TTL Encoder (bipolar wiring)	50
5.10.8.2 TTL Encoder (unipolar wiring)	51
5.10.9 SIN/COS Encoder (X11)	51
5.10.10 Tacho (X13)	51
5.10.11 Sine Encoder with Hall (X13)	52
5.10.12 Encoder with BiSS (X11)	52
5.10.13 AMR-Encoder (X11)	53
5.11 Analog and digital inputs and outputs	54
5.11.1 Analog inputs and outputs	54
5.11.2 Digital inputs and outputs	54
5.12 RS-232 interface, PC connection (X2)	55
5.13 CAN interface (X10)	56
5.14 Ethernet interface	56
5.15 EtherCAT interface	56
5.16 USB interface (X3-1)	56
6 Controller Monitoring with SetUp Tool SWM7.exe	57
6.1 General	57
6.2 Interfaces and Settings	58
6.3 Using the SWM7 SetUp tool	58
6.3.1 Installation of the software	58
6.3.1.1 Hardware requirements	58
Communication interface:	58
6.3.1.2 Installation under Windows OS	58
6.3.1.2.1 Genuine RS-232 interface	58
6.3.1.2.2 USB-to-serial adapter	58
6.3.1.3 Installation under Linux OS	58
6.3.2 Putting into operation	59
6.3.2.1 Standby operation without connected motor	59
6.3.2.2 Operation with connected drive	61
6.3.3 Guide for setup	61
6.4 Operational tasks	61
6.4.1 Loading/Saving a Parameter Value Set	62
6.4.2 Enable drive/Disable drive	62
6.4.3 Adding parameter displays to a page	62
6.4.3.1 Meaning of formatting in the "Parameters" window	63
6.4.3.2 Meaning of formatting in a parameter display	63
6.4.4 Delete parameter display of a page	63
6.4.5 Creating user-defined tabs	64
6.4.6 Deleting user-defined tabs	64
6.4.7 Restoring default GUI layout	64
6.5 Description of menus and windows	65
6.5.1 Menu items	65
6.5.1.1 File menu	65
6.5.1.2 Settings tab	65
6.5.1.3 Parameters tab	65
6.5.1.4 Service menu	66
6.5.1.5 Type Plate tab	66
6.5.1.6 About tab	66
6.5.2 Related files (GUI layout *.mac, parameter file *.macp)	66

6.6	Error Messages.....	67
6.6.1	Handling of RS-232 communication errors.....	67
6.6.1.1	Message "Transmitting Telegram: No Response".....	67
6.6.1.2	Message "COM Error 0x02".....	67
6.6.2	Errors regarding wrong setup in SWM7 GUI.....	68
6.6.2.1	Invalid combination of feedback sensors.....	68
6.6.2.2	Missing motion sensors.....	68
6.6.2.3	Incomplete sensor definitions.....	68
6.6.3	Runtime Errors.....	69
6.6.3.1	Over Voltage.....	69
6.6.3.2	Under Voltage.....	69
6.6.3.3	Over Current.....	69
6.6.3.4	Over temperature heat sink.....	69
6.6.3.5	Error on resolver.....	69
6.6.3.6	I*t warning.....	70
6.6.3.7	I*t error.....	70
6.6.4	Other error messages related to SWM7 program.....	70
7	System Parameters Setup _TBD_.....	71
7.1	How to use the User Manual.....	71
7.1.1	Target group.....	71
7.2	Motor Definitions.....	71
7.3	Speed and Current definition (Setup).....	71
7.3.1	Current Loop.....	71
7.3.1.1	Current control P gain / I gain / D gain.....	72
	Parameter identification by optimization of current step response:.....	74
7.3.2	Speed Loop.....	75
7.3.2.1	Speed control P gain / I gain / D gain.....	75
7.3.2.2	Speed: Max. Acceleration / Deceleration.....	75
7.3.2.3	Speed: Ramp.....	75
7.3.2.4	Speed: Max. Acceleration / Deceleration.....	75
7.3.2.5	Tach Lowpass, MAF.....	75
7.3.2.6	Tach Lowpass, PT1.....	76
7.4	Display Information on SWM7 GUI.....	76
7.4.1	Examine parameters file.....	76
7.4.2	Parameter window or measuring window marked in red.....	77
7.4.3	SWM7 control windows.....	77
7.4.3.1	Control windows in "POSITION CONTROL" tab.....	78
7.4.3.2	Control windows in "SENSORLESS CONTROL" tab.....	80
7.4.3.3	Control windows in "FIELD WEAKENING" tab (TBD).....	82
7.4.3.4	Control windows in "PHASE FINDING" tab.....	84
7.4.3.5	Control windows in "CAN" tab.....	86
7.4.3.6	Control windows in "OFFSET" tab.....	88
7.4.3.7	Control windows in "MOTION SENSOR MONITORING" tab.....	90
7.4.3.8	Control windows in "SPEED / CURRENT CONTROL" tab.....	94
7.4.3.9	Control windows in "MOTION SENSORS" tab.....	98
7.4.3.10	Control windows in "SYSTEM SETUP" tab.....	102
7.4.3.11	Control windows in "SWM STATUS" tab.....	103
7.4.3.12	Control windows in "DATA ACQUISITION" tab.....	106
7.4.3.13	Control windows in "COMMAND INPUT SELECT" tab.....	111
7.4.3.14	Control windows in "ANALOG INPUT" tab.....	113
7.5	Operational tasks with SWM7 GUI (TBD).....	115
7.5.1	Recommended sequence for operation (TBD).....	115
7.5.1.1	System setup.....	117
7.5.1.2	Data Acquisition.....	117
7.5.1.3	Sensorless control.....	119
7.5.1.4	Speed / Current Control (TBD).....	119
7.5.1.5	SWM status.....	120
7.5.1.6	CAN.....	121
7.5.1.7	Field weakening.....	121
7.6	Optimization.....	122

---

7.7 Save Settings.....	124
7.8 Error Messages.....	124
7.8.1 Error matrix .....	124
7.9 Trouble Shooting.....	125
8 Glossary.....	128
9 Index.....	133
10 EMC Recommendations.....	137
10.1 External filtering measures.....	137
10.1.1 AC Mains filter .....	137
10.1.2 DC Mains filter.....	137
10.2 Additional filtering measures.....	137
10.3 Motor chokes.....	138
10.4 Mounting Instructions.....	139



## List of Tables

Tab. 2.1: SWM7S name plate (example).....	18
Tab. 3.1: SWM7S related electrical data.....	20
Tab. 3.2: Inputs, outputs and aux. voltage supply.....	20
Tab. 3.3: SWM7S connectors.....	21
Tab. 5.1: Connection drawings (overview).....	33
Tab. 5.2: SWM7 connector assignments.....	34
Tab. 5.3: SWM7 digital inputs.....	54
Tab. 5.4: SWM7 digital outputs.....	55
Tab. 6.1: Definitions for display of parameter, measuring and selection windows.....	62
Tab. 7.1: PID variables.....	72
Tab. 7.2: Lowpass configuration values for resolver operation.....	76
Tab. 7.3: Control windows in "POSITION CONTROL" tab.....	80
Tab. 7.4: Control windows in "SENSORLESS CONTROL" tab.....	82
Tab. 7.5: Control windows in "FIELD WEAKENING" tab.....	84
Tab. 7.6: Control windows in "PHASE FINDING" tab.....	86
Tab. 7.7: Control windows in CAN tab.....	88
Tab. 7.8: Control windows in OFFSET tab.....	89
Tab. 7.9: Control windows in "MOTION SENSOR MONITORING" tab.....	94
Tab. 7.10: Control windows in "SPEED / CURRENT CONTROL" tab.....	98
Tab. 7.11: Control windows in "MOTION SENSORS" tab.....	101
Tab. 7.12: Control windows in "SYSTEM SETUP" tab.....	103
Tab. 7.13: Control windows in "SWM STATUS" tab.....	105
Tab. 7.14: Control windows in "DATAACQUISITION" tab.....	110
Tab. 7.15: Control windows in "COMMAND INPUT SELECT" tab.....	113
Tab. 7.16: Control windows in "ANALOG INPUT" tab.....	114
Tab. 7.17: Sequence for operational tasks.....	116
Tab. 7.18: Error matrix.....	124
Tab. 7.19: Trouble Shooting for different faults (examples).....	125
Tab. 10.1: AC Mains filter (before the transformer).....	137
Tab. 10.2: Motor chokes (optional).....	138

## List of Figures

Figure 4.1: Mounting drawing for 188 x 164 mm base plate.....	27
Figure 4.2: Mounting drawing for 188 x 189 mm base plate.....	28
Figure 4.3: Mounting drawing for SWM7 300...600 high voltage, wall mount version.....	29
Figure 4.4: 3D view for SWM7 300...600 high voltage, wall mount version.....	30
Figure 5.1: Connection diagram (Overview).....	35
Figure 5.2: SWM7S-48/150 connectors.....	36
Figure 5.3: Connectors for SWM7-48/150 with extended I/O.....	37
Figure 5.4: Connectors for SWM7-48/100 (M6 motor connectors).....	38
Figure 5.5: Connectors for SWM7S 300/600.....	39
Figure 5.6: Power supply SWM7 (X5).....	40
Figure 5.7: Temperature supervision (X3).....	40
Figure 5.8: Command interface (X2).....	41
Figure 5.9: Enable interface (X1).....	41
Figure 5.10: DC3 motor connection SWM7 (X4).....	42
Figure 5.11: DC1 motor connection SWM7 (X4).....	42
Figure 5.12: Motor brake (X3).....	42
Figure 5.13: Hall sensors (X13).....	43
Figure 5.14: Resolver (X9).....	45
Figure 5.15: Encoder differential.....	46
Figure 5.16: Encoder unipolar.....	47
Figure 5.17: Encoder with EnDat.....	48
Figure 5.18: Netzer Encoder.....	49
Figure 5.19: DC Tacho.....	49
Figure 5.20: TTL Encoder (bipolar wiring).....	50
Figure 5.21: TTL Encoder (unipolar wiring).....	51
Figure 5.22: SIN/COS Encoder.....	51
Figure 5.23: Tacho.....	52
Figure 5.24: Sine Encoder with Hall.....	52
Figure 5.25: Encoder with BiSS.....	53
Figure 5.26: AMR- Encoder (X11).....	53
Figure 5.27: PC connection to SWM7.....	55
Figure 5.28: CAN connection to SWM7.....	56
Figure 6.1: MACCON SWM7 SETUP main window (example) .....	60
Figure 6.2: Choose Serial Port (example COM3).....	60
Figure 6.3: SWM Message window (example no error).....	60
Figure 6.4: "Write Parameters to Flash" button.....	62
Figure 6.5: "Enable Drive" and "Disable Drive".....	62
Figure 6.6: Adding parameter "Profile: Max. Acceleration" to a section (example).....	63
Figure 6.7: Delete measuring window "Profile State" (example).....	63
Figure 6.8: "Add Sheet" option.....	64
Figure 6.9: Create caption "Voltages" (example).....	64
Figure 6.10: "Remove Sheet" selection.....	64
Figure 6.11: Windows "Device Manager" window.....	67
Figure 6.12: Port Settings for the COM port (default).....	67
Figure 6.13: Adjust Receive Buffer for COM port.....	68
Figure 6.14: Duplicate Use Of Encoder Input 2.....	68
Figure 6.15: Missing Motion Sensors.....	68
Figure 6.16: No Hall Sensor Type defined.....	69
Figure 6.17: Over voltage.....	69
Figure 6.18: Over temperature heat sink.....	69
Figure 6.19: I*t warning.....	70
Figure 7.1: PID Control system.....	72
Figure 7.2: Display of response on a 2-channel oscilloscope (insert original screenshot ??).....	73
Figure 7.3: PID testing.....	74
Figure 7.4: Parameter "Tach Lowpass, PT1".....	76
Figure 7.5: "Parameter Preview" window.....	77

---

Figure 7.6: "CAN Transmit Mode" not present in current firmware.....	77
Figure 7.7: Field Weakening Mode.....	121
Figure 7.8: Rotor vectors (voltage and current).....	122
Figure 7.9: Optimum PID coefficients.....	123
Figure 7.10: PID Control system (result).....	124
Figure 10.1: DC mains filter (SWM7S input filter) technology acc. chap. 10.1.2 .....	138
Figure 10.2: SWM HV (High voltage) Controller Supply.....	139
Figure 10.3: SWM7S cable shield.....	140



# 1 Introduction

This User Manual describes the SWM7S series of digital servo controllers

- Handling and Package, see chap. 2
- Technical Description, see chap. 3
- Mechanical Installation, see chap. 4
- Electrical Installation, see chap. 5
- SetUp Tool **SWM7.exe**, see chap. 6
- Operation, see chap. 7
- Glossary in chap. 8, EMC Consideration see chap. 10 and Index, see chap. 9.

All the operation functionality is accessible via the user-friendly and customizable Graphical User Interface (GUI), including Control windows for

- display of all operational states, parameters and measurement values
- configuration and optimization for efficient working order
- searching for malfunctions, if any.

The SetUp Tool **SWM7.exe** enables set-up and fine tuning of connected hardware (e.g. sensors, motors, etc.), and software updates.

The user gets flexible framework, so additional functionality can easily and efficiently be implemented according to the individual needs.

All the software and User Manual required for the operation of SWM7S is electronically available on CD-ROM and if necessary in paper form also.



Pay attention to the Safety Instructions, to avoid any risk for dangerous voltages, temperatures and hardware damage.





First check the chap. 7.9, “ Trouble Shootingg” on page 123.

In case of errors, hardware problems (e. g. fuses, connectors, capacitor reforming, user-specific settings etc.) or other service related questions contact MACCON tech support or phone +49 89 651220-0.

## 1.1 About this manual

This User Manual available in a PDF formatted file can be read and print-out by any commercial and freeware PDF reader, e.g. Acrobat Reader or Foxit Reader.

Some hints and tips for usage:

- ✓ The PDF file is fully linked, i. e. you can access to any linked topic.
- ✓ Efficient navigation is possible if you open in the left pane of the PDF reader the Table of Contents or List of Tables.
- ✓ Using the “Search” functionality in the reader software you can find any word item. But how to get back to the previous page?  
Use the “Previous View” button like  in the status bar or the key buttons <Alt+left> or <Alt+right> for “Next View” like .

- ✓ This User Manual is numbered from the cover page beginning with “1” to “n”. So you can use the numbered pages for a direct print-out or navigation in accordance to the numbering e.g. in Table of Contents or List of Tables.
- ✓ Last not least – all colored drawings were tested for a readable print-out on a LaserJet. Using specific print settings you can print the User Manual on single pages, double pages or multiple pages in front view or landscape view.
- ✓ Annotations, comments or bookmarks in the PDF file can be set and used in relation to the PDF reader features. For details see in Online Help of the reader tool. If needed, you can attach files into the PDF User Manual.

### 1.1.1 Target group

Only qualified personnel are permitted to perform activities such as transportation, installation, commissioning and maintenance.

### 1.1.2 Structure of this manual

For further details see in “Table of Contents”, page 5.

### 1.1.3 Related documentation

This User Manual serves for detailed view of all applications related to the most used hardware components, accessories and software.

Additional documentation:

- Product data sheet and service information delivered by MACCON
- Description of accessories, e.g. cables, fuses, connectors etc.
- Technical data and operational notes of motors, servos, encoders and interfaces.
- ✓ See on Change History in this manual that all revisions in relation to the hardware components.

## 1.2 Restrictions

None

## 1.3 Safety Instructions

Each chapter contains specific instructions to avoid any hazardous situation which, if not avoided, will be result of death serious, minor or moderate injury.

MACCON disclaims all responsibility and guarantee in case of misuse of hardware and failure to comply with the instructions provided in this manual.

## 1.4 Typographical conventions

### Graphical user interface text

Text of the graphical user interface (window titles, button descriptions, etc.) is placed inside quotation marks.

*Example:*

In the "POSITION CONTROL" tab choose in the control window "Start Current (DC)" the start value of 5.0 %

**File names**

File names and paths are represented by a special font.

*Example:*

Start the **SWM7.exe** file. Install the program in the following directory:

d:\Programs\SWM7

**Variables**

Place holders for real names and values are represented additionally in italics and angle brackets.

*Example:*

Use the \*.exe file *<installation path>\SWM7.exe*





## 2 Handling and Package

Keep the original box for any transport of the device!

After a storage period of more than 12 months check with MACCON tech support if any capacitor reforming might be necessary before powering the device!

### 2.1 Packaging, Transport and Storage

- Max. stacking height  $\leq 8$  cartons
- For transport keep the original box and insert for any transport of the device.
- Storage temperature  $-25$  to  $+55^{\circ}\text{C}$ ,  $\leq 95\%$ , 2 years  
Storage only in the manufacturer's original recyclable packaging.

### 2.2 Maintenance and Cleaning

No customer maintenance is necessary. There are no user serviceable parts inside the device.

Hints for cleaning:

- If the casing is dirty – clean with Isopropanol or similar solvent.  
Do not immerse or wash directly in the fluid.
- Controller and internal parts:  
Return to manufacturer for cleaning and testing.

### 2.3 Disassembling

Observe the sequence below, if a servo amplifier has to be disassembled (e.g. for replacement).

1. Electrical disconnection  
Switch off the main switch of the switch gear cabinet and the fuses that supply the system.  
Wait at least eight minutes after disconnecting the servo amplifier from the main supply power before touching potentially live sections of the equipment (e.g. contacts) or undoing any connections.  
To be sure, measure the voltage in the DC supply and wait until it has fallen below 40 V.

Remove the connectors. Disconnect the earth (ground) connection at last.

2. Check temperature  
During operation the heat sink of the servo amplifier may reach temperatures above  $80^{\circ}\text{C}$  ( $176^{\circ}\text{F}$ ).  
Before touching the device, check the temperature and wait until it has cooled down below  $40^{\circ}\text{C}$  ( $104^{\circ}\text{F}$ ).
3. Disassembling  
Disassemble the servo amplifier (reverse of the procedure described in chap. 4).

### 2.4 Repair Instructions

Repair of the servo amplifier must be done by the manufacturer.



Opening the devices means loss of warranty.

In case of service related questions contact MACCON tech support or phone +49 89 651220-0.

## 2.5 Disposal



Disassemble the equipment as described in chap. 2.4 and send it in the original packaging to the address given in the dispatch information.

By a specialized disposal company, certified for the disposal of electronic equipment. The controller contains electronic components and PCBs, metal parts are made of copper, steel or aluminum.

## 2.6 Package

When a controller from the SWM7S series is ordered, the following is supplied, see chap. 2.6.1.

### 2.6.1 Package supplied

1. Drive
  - Servo controller SWM7S
  - CD-ROM, contain SWM7S software, firmware for microcontroller ( $\mu$ C), DSP, FPGA, customer specific parameters (optional) and the User Manual SWM7S
  - Mating connectors for the motor and the DC/auxiliary supply are included in delivery as well as the RS-232 cable.  
The mating SubD connectors are **not** part of the package!
2. Accessories (must be ordered separately, if required, contact MACCON Sales)
  - motor cable (prefabricated) with special shield clamp, or both power connectors separately, with the motor cable as a cut-off length
  - feedback cable (prefabricated) or both feedback connectors separately, with the feedback cable as a cut-off length
  - motor choke 3YL/3YLN, for motor cables longer than 25 meters
  - communication cable to the PC, see chap. page 57 and chap. 6.6.1 for setting parameters from a PC
  - power cable, control cables, field bus cables (as cut-off lengths)
  - CANbus activation, CAN profile.

### 2.6.2 Nameplate for HW and SW

On request of MACCON tech support you must identify the present hardware (HW) and software (SW).

#### 2.6.2.1 Hardware

The name plate, see Tab. 2.1, and is placed on the back of the SWM7S housing. The version, part number, serial no. and option is assigned by the product administration system.

<b>Type:</b>	SWM7S-048-50-ET		
<b>Supply:</b>	48-60V		
<b>Modification:</b>	n/a		
<b>Version:</b>	Rev. D4	<b>Option:</b>	D2
<b>Part No.</b>	12.0251	<b>Serial No.:</b>	1428.7027

Tab. 2.1: SWM7S name plate (example)

#### 2.6.2.2 Software

To identify the present PC SW version – see in “About” tab.

The firmware consists of three separate modules for  $\mu$ C, DSP and FPGA. Regarding the DSP and FPGA firmware select the tab “SWM STATUS”, see control window “DSP SW Version” and control window “FPGA Version”. The  $\mu$ C firmware version is reported as first message after start-up in the message window.

## 3 Technical Description

The SWM7S is used for the current feed and control of servo motors (Sine Wave Monitored servo controller), and represents the culmination of 20 years of development and application experience in industrial, military and vehicle servo systems.

This motor controller family offers the benefits of modern digital and power electronics technology. Some of the special features of this motor controller are:

- Power section
  - power stage for DC- brush, 3-phase brushless DC- and AC- induction motors
  - various voltage supply ranges (12...60 V, 12...350 V, 24...650 V), 24 V aux. supply.
- Auxiliary supply voltage 24 V DC
  - range 12...60 V DC (max. 25 Watt)
- General
  - industrial (– CT), extended (– ET) temperature versions and MIL-types (– MT) available
  - $\pm 10$  V analog interface for torque or speed control
  - CANbus-interface, also for positioning purposes
  - CANaerospace, ARINC 825 and customized communication profiles available
  - sine- ware or block- commutation using hall effect, resolver or encoder feedback
  - velocity feedback via DC- Tach, resolver, encoder or hall effect devices
  - high-efficiency PWM (15/20/25/30/40 kHz ) with parallel modulation
  - high-bandwidth, linear current control (12.5  $\mu$ s current loop calculation)
  - 100 % digital set-up of drive parameters including current loop
  - multiple digital and analog I/O's
  - accordant to CE, MIL-STD-810, -461/462, -1275B (48 V versions) etc.
  - high reliability – 20.000 hrs to MIL-HDBK- 217F (NS- naval sheltered)
  - connector panel adaptable to special connectivity requirements, SWM7S short version
  - parameter monitoring and configuration from a PC via the USB/RS-232-interface
  - configuration software under Microsoft Windows OS.
- Inputs and Outputs
  - analog set value
  - analog outputs (visualization of fundamental signals/real-time analyzable)
  - digital outputs (debug, enable)
  - digital outputs error.
- Integrated safety
  - external enable signal (hardware input)
- Operation and parameter setting
  - completely digital controlled
  - current, velocity, position
  - parameterization control loops
  - configuration of feedback sensors
  - configuration of inputs and outputs.

### 3.1 SWM7S family of digital servo controllers

A drive version with a linear (non-switching) power stage is available in the same housing and with the same motor and control interface configurations as the SWM7. The LWM7S has excellent linearity around zero current, unsurpassed EMC- characteristics and no PWM- jitter.

It is ideal for critical applications in science and medicine as well as in semiconductor and magnetically sensitive environments, e.g. for positioning with sub- nanometer resolutions.

### 3.1.1 Technical data

The Tab. 3.1 below shows all SWM versions:

Rated electrical data	SWM048 and SWM300-xxx-x				
Rated supply voltage	48 V DC, 48 V DC, 300 V DC				
Maximum supply voltage	60 V DC, 320 V DC				
Logic supply voltage	12...60 V DC				
Switching threshold over voltage					
SWM048	80 V				
SWM150-xxx-x	360 V				
Rated phase current					
SWM048	–	12.5 Arms	25 Arms	50 Arms	100 Arms
SWM300-xxx-x	5 Arms	12.5 Arms	25 Arms	–	–
Form factor – output current	< 1.01				
Bandwidth – current control	> 3 kHz				
Clock frequency output stage linear	20, 40 kHz (configurable by SWM7 software)				
Power dissipation (output stage locked)	0 W				
Analogous index value, input resistance	± 10 V, 50 kOhm				
Current resolution	16 Bit x current vector				
Max. commutation frequency	2 kHz				
Encoder					
TTL Incremental encoder	A, /A, B, /B, Z, /Z				
Sinus/Cosinus	AUX1, AUX2, IDX				
Resolver	16 Bit; 5 kHz; 6 – 25 kHz; 8,33 kHz; 10 kHz				
Digital index value	15, 20, 25, 30, 40, 50 kHz PWM, 5 V 10 Bit (50:50 or 0:100 impulse rest ratio)				

**Tab. 3.1:** SWM7S related electrical data

Interface electrical data	SWM048 and SWM300-xxx-x
Analog inputs	±10 V
Digital control inputs	5...36 V DC
High speed Digital Input	HS_IN 1, 2, 3; 3.3 V
Digital control outputs	open-collector max. 30 V DC, 100 mA
Relay contacts	max. 30 V DC, max 42 V AC 500 mA
Auxiliary supply voltage electrically isolated for > 300 V power stage	12...60 V
Current without motor brake	1 A at 24 V
Min./max. output current to brake	2 A, separated external supply

**Tab. 3.2:** Inputs, outputs and aux. voltage supply

Designation	Connector	Type	max. Cross section in mm <sup>2</sup>	max. Current	max. Voltage
Control signals					
Aux. voltage	X3-4	FCT	1.5	2 A	12...60 V
Motor	X4	FCT	16.0	80 A	0...600 V
Power signals	X5	FCT	16.0	80 A	0...600 V
Resolver input	X1	Sub-D, 9 pole female	0.5 AWG20	150 mA	± 15 V
Encoder input	X6	Sub-D, 9 pole male	0.25	10 mA	0...5 V
Signal connector	X2	Sub-D, 25 pole female	0.25	60 mA	0...5 V
Sine and Serial Encoder Input	X11	Sub-D, 15 pole female	0.25	60 mA	0...5 V

Interface for

PC RS-232	X2-1	RJ11, 4 pole	0.11 AWG27	10 mA	± 15 V
USB	X3-1	USB-B, 4 pole	0.11 AWG27	10 mA	0...5 V
Ethernet	X4-1	RJ45	0.11 AWG27	10 mA	10 V
Test Box (TB)	X1-1	RJ12	0.11 AWG27	10 mA	0...5 V

Tab. 3.3: SWM7S connectors

### 3.1.2 Fusing

The fusing depends on device type only and accessible after opening the case.



Opening the device means loss of warranty!

In SWM7S are present:

- Main fuse (placed inside SWM 7), see chap. 5.6: (Manufacturer Fa. Bussmann FWP-xx)

SWM7 48/60 V		SWM7 High voltage	
I <sub>nom</sub>	Type	I <sub>nom</sub>	Type
12.5 A	25 LET	12.5 A	25 ET
50 A	100 LET	25 A	56 ET
100 A	160 LET	80 A	80 ET



Fuses may only replaced by MACCON tech support – without loss of warranty. In the case of no power output (e. g. after a short circuit of the motor lines) contact MACCON tech support or via phone +49 89 651220-0.

- Aux. fuse – mounting by the user:  
 European types: gRL or gL 400/500 V, e.g. 10 A T (T= slow)  
 US Types: Security classes RK5, CC, J or T, 600 V AC e.g. 100 kA, time delay

### 3.1.3 Ambient conditions, ventilation and mounting position

<b>Storage temperature</b> .....0...+ 55° C	[°F]= 1.8 x [°C] + 32
Humidity.....≤ 95 %	
Max. period.....2 years	
<b>Transport temperature</b> .....– 20...+ 70° C	[°F]= 1.8 x [°C] + 32
Humidity.....≤ 95 %, without condensation	
<b>Environmental conditions</b>	
Environmental temperature	in operation
CT.....0...+ 45° C	[°F]= 1.8 x [°C] + 32
ET/MT.....– 40...+ 65° C	
with power derating 2.5 %/° C.....+ 40...+ 55° C	
Humidity.....rel. humidity 85 %, no condensation	
<b>Site altitude</b>	
without derating.....up to 1.000 m over sea	
with power derating 1.5 %.....1.000... 2.500 m over sea	
<b>Enclosure protection</b> .....IP50, acc. to IEC 60529	<b>TBD</b>
<b>Mounting</b> .....no restrictions	
	allow for free convection and base plate cooling (≤ 85° C)
<b>Cooling</b> .....depends on mounting, free convection should be possible	

### 3.1.4 Conductor cross-sections

The conductor cross sections must be in relation to standards  
 – IEC 204-1  
 – VDE 0298-4  
 compare with these current ratings.

### 3.1.5 Mechanical data

The SWM7S controllers are mounted on a base plate and completely sealed to ensure good physical protection and EMC both.

The dimensions are:

	<b>SWM7/048-*</b> <b>SWM7-PSU</b>	<b>SWM7/048</b> <b>100 &amp; 150</b>	<b>SWM7/x00–12.5 &amp; 25–</b> <b>AC</b>	<b>SWM7/x00–12.5 &amp; 25–</b> <b>WC</b>
Length / mm	186	187	214	254 (230) <sup>1)</sup>
Width / mm	189	181	216	260 (218) <sup>1)</sup>
Height / mm	92.5	113	155	125
Weight / kg	2.0	2.5	7.5	3.5

**AC:** forced air cooling  
**WC:** water cooling

\* SWM7S/... version with 65 mm height available  
<sup>1)</sup> Dimension heat sink

MACCON offers a Power Supply Unit (PSU) also applicable for SWM7S with dimensions L x W x H = 186 x 189 x 92.5 mm.

### 3.1.6 Grounding system

The grounding system contains the following:

1. AGND – analog inputs, internal analog ground
2. DGND – 24 V -I/O, digital inputs/outputs, optically isolated
3. GND – internal digital ground encoder emulation
4. GND – separate digital ground for RS-232, and CAN.

### 3.1.7 Switch-on and switch-off behavior

Depending on "power-on enable state" and use of external enable switch, the unit can apply motor power shortly after connecting the supply.

The power stage will be disabled in case of internal failure condition.





## 4 Mechanical Installation

The mechanical installation has to be treated and handled carefully in accordance with the technical data, see chap. 3.1.1 and ambient conditions see chap. 3.1.3 .

### 4.1 Safety Instructions



There is a danger of electrical shock by high EMC level which could result in injury, if the servo controller (or the motor) isn't properly EMC- grounded. Do not use painted (i. e. non-conductive) mounting plates.

Protect the servo controller from impermissible stresses. In particular, do not let any components become bent or any insulation distances altered during transport and handling. Avoid contact with electronic components and contacts.



Do not mount devices, which produce magnetic fields, directly beside the servo controller. Strong magnetic fields could directly affect internal components. Install devices which produce magnetic field with distance to the servo controllers and/or.

In case of errors, hardware problems (e.g. fuses, connectors, capacitor reforming, user-specific settings etc.) or other service related questions contact MACCON tech support or phone +49 89 651220-0



The servo controller will switch-off itself in case of overheating. Ensure that there is an adequate flow of cool, filtered air into the bottom of the control cabinet, or use a heat exchanger – refer to chap. 3.1.3.

### 4.2 Guide to mechanical installation

The following notes should help you to carry out the mechanical installation.

- Site

In a closed control cabinet – refer to chap. 3.1.3. The site must be free from conductive or corrosive materials. For the mounting position in the cabinet – see on page 26.

- Ventilation

Check that the ventilation of the servo controller is unimpeded, and keep within the permitted ambient temperature, see chap. 3.1.3. Keep the required space clear above and below the servo controller detailed on page 22.

- Assembly

Assemble the servo controller and power supply close together, on the conductive, grounded mounting plate in the cabinet.

- Grounding Shielding

For EMC- compliant shielding and grounding see on page 133. Ground the mounting plate, motor housing and GND of the control system. Notes on connection techniques detailed see chap. 10.4 on page 135.

### 4.3 Dimensions

Check the mounting for a maximum air ventilation based on the mechanical data, see chap. 3.1.5 on page 22.

### 4.4 Assembly (TBD)

The SWM modules are mounted on a base plate and are completely sealed. Main connections are made via military-style Sub-D or screw connectors.

For details see Fig. 4.2 to Fig. 4.4.

The motor power cable consists of four wires:

- Phases U, V, W and an additional
- Earth wire (PE ground – protective earth ground connection).
- Use a 4-wire shielded (not twisted) cable for motor connections, see table on chap. 3.1.4.
- Mount the cable shield closest to motor housing and PE ground.
- Connect the other end of the cable shield closest to
  - X5-4 and X5-5 (SWM7S – see chap. 5.5.1 on page 36)
  - X5-4 and X5-5 (SWM7 – 48/150 with extended I/O), see chap. 5.5.2 on page 37)
  - M-GND (SWM7-48/100), see chap. 5.5.3 on page 38.
- GND of the SWM7 – for details see on Fig. 5.9.

#### 4.4.1 Base plate 188 x 164 mm

The device SWM7S 48/150 is mounted from below by six M4 screws according to the drawing below.



Do not mount screws > 6 mm + material thickness of mounting plate used!






Figure 4.1: Mounting drawing for 188 x 164 mm base plate

**4.4.2 Base plate 188 x 189 mm**




**Figure 4.2:** Mounting drawing for 188 x 189 mm base plate

**4.4.3 SWM7 –300 V / –600 V wall mount version, high voltage**



**Figure 4.3:** Mounting drawing for SWM7 300...600 high voltage, wall mount version



**Figure 4.4:** 3D view for SWM7 300...600 high voltage, wall mount version

Position	Designation
1	Mounting plate
2	Support
3	Ventilating fan
4	Protective grating
5	M4 Spacer keeps
6	Cylinder head screws M5x10 (8 pcs. cylinder head screws for for mounting on Pos. 1)
7	Cylinder head screws M5x10
8	Hex-nut

## 5 Electrical Installation

This chapter deals with

- Safety Instructions, see below
- Guide to electrical installation, see below
- Wiring, see on page 32
- Connector assignments, see on page 34
- Connection diagrams (Overview), see on page 35
- Power supply (X5), see on page 40
- Temperature supervision (X3), see on page 40
- Enable and command interface (X1), (X2), see on page 41
- Motor brake connection (X4), see on page 41
- Feedback, see on page 43
- Digital and analog inputs and outputs, see on page 52
- RS-232 interface, PC connection (X2), see on page 54
- CAN interface (X10), see on page 54
- Ethernet interface, see on page 54
- Digital and analog inputs and outputs, see on page 55.

### 5.1 Safety Instructions



Pay attention to the Safety Instructions, to avoid any risk for dangerous voltages, temperatures and hardware damage.



First check the chap. “ Trouble Shooting” 7.9.

In case of errors, hardware problems (e.g. fuses, connectors, capacitor reforming, user-specific settings etc.) or other service related questions contact MACCON tech support or phone +49 89 651220-0



During operation, servo controllers may have hot surfaces. Since the base plate is used as a cooling element, it may reach temperatures up to 85° C, i. e. 185° F.

### 5.2 Guide to electrical installation

- Cable selection  
Select cables in accordance with IEC 60204
- Grounding Shielding  
For EMC- compliant shielding and grounding – ground the mounting plate, motor housing and GND of the control system.
- Wiring



Route power leads and control cables separately.  
Use an emergency stop circuit in your installation !

- Check the allocation of servo controller and motor, and compare the rated voltage and current ratings.

- Pay attention to proper grounding of the servo controller and motor housing. Use for motor, encoder and control cables shielded cables with sufficient cross section (EN 60204), see Fig. 5.1.
- As motor cable is used a shielded cable
  - 4-wire cable (for DC3, brushless, 2 phases) motor, see Fig. 5.8
  - for DC brush motors needed a 3-wire cable only, see Fig. 5.9.
- Place the shield over a large area (low resistance) at both ends to ground. Specifically, the connection of the motor cable shield (connector X4) should lie on both sides of SWM housing or motor housing.

### 5.2.1 Sequence for installation:

1. Connect the digital control inputs and outputs.
  2. Connect the analog input source, if required.
  3. Connect the feedback device.
  4. Connect the motor cable
  5. Connect shielding to EMC connectors (shield connection) at both ends. Use the motor choke (3YL/3YLN) if cable  $\geq$  25 meters.
  6. Connect the auxiliary supply.
  7. Connect the main electrical supply.
  8. Connect the PC.
- Final check  
Final check of the implementation of the wiring against the wiring diagrams that have been used.

## 5.3 Wiring

The installation procedure is described as an example. A different procedure may be appropriate or necessary, depending on the application of the equipment. We provide further know-how through training courses (on request).

### 5.3.1 Safety Instructions



Pay attention to the Safety Instructions, to avoid any risk for dangerous voltages, temperatures and hardware damage.



There is a danger of electrical arcing with serious personal injury. Only install and wire up the equipment when it is not live, i. e. when neither the electrical supply nor the 24 V auxiliary voltage nor the supply voltages of any other connected equipment is switched on.

Take care that the cabinet is safely disconnected (with a lock-out, warning signs etc.).



Only professional staff who are qualified in electrical engineering are allowed to install the servo controller.

### 5.3.2 Connection diagrams

For details of the connection drawings, see on Table 5.1.



Denomination	see on
Overview	page 35
Motor	page 41
Feedback	page 43
Digital and analog inputs and outputs	page 52
CAN interface	page 54
USB interface	page 55
Ethernet interface	page 54

**Tab. 5.1:** Connection drawings (overview)

### 5.3.3 Shielding connection to the front panel

For details see Fig. 5.1.

### 5.3.4 Motor connector X4 with shielding connection

For details see

- Overview Fig. 5.1 (page 35)
- DC3 motor Fig. 5.7 on page page 40 and
- DC1 motor Fig. 5.8 on page 41.

### 5.3.5 Technical data for connecting cables

For further information on the chemical, mechanical and electrical characteristics of the cables please refer to the accessories manual or contact our customer service. Observe the rules in the section "Conductor cross-sections" on page 22.

To reach the max. permitted cable length, you must use cable material that matches the recommended capacitance requirements of  $\leq 150$  pF/m.

## 5.4 Connector assignments

The following table details the connector assignments.

	<b>SWM7S-048-XX-XX-ET/CT</b>	<b>SWM7S-300/600-XX</b>	<b>SWM7-048-100R (** AMR option)</b>
<b>Communication</b>			
RS-232	<b>X2-1</b>	<b>X2-1</b>	<b>X2-1</b>
USB	<b>X3-1</b>	<b>X3-1</b>	<b>X3-1</b>
CAN	<b>X10</b>	<b>X10</b>	<b>X10</b>
Ethernet	<b>X4-1</b>	<b>X4-1</b>	<b>X4-1</b>
<b>Power &amp; Motor</b>			
Thermo/Brake	<b>X3</b>	<b>X3</b>	<b>X3</b>
Motor	<b>X4 SubD HS-8</b>	Phoenix 4 pole	M6 Screw
DC PWR + Control	<b>X5 SubD HS-5</b>	<b>X5 SubD HS-2 ctrl</b> Phoenix 3 pole (PWR)	X5 SubD HS-5
<b>Feedback</b>			
Resolver	<b>X1</b>	<b>X1</b>	<b>X1</b>
Encoder	<b>X6</b>	<b>X6</b>	<b>X12</b>
AUX supply	–	<b>X5</b>	–
Encoder Out	–	–	<b>X8</b>
Sine + Serial	<b>X11 (Sine/serial/** AMR)</b>	<b>X11 (Sine/serial/** AMR)</b>	<b>X11 (Sine/serial/** AMR)</b>
Sine + TTL	–	–	<b>X12</b>
Tach / Hall	<b>X13</b>	<b>X13</b>	<b>X13</b>
<b>I/O Standard</b>			
Test Box	<b>X1-1</b>	<b>X1-1</b>	<b>X1</b>
Digital/Analog/EncOut	<b>X2</b>	<b>X2</b>	<b>X8</b>
Digital In/Out/Rel Optoisol.	<b>X7</b>	<b>X7</b>	–
<b>I/O extended</b>			
Test Box	–	–	<b>X1-1</b>
Analog In	–	–	<b>X14</b>
Analog Out	–	–	<b>X15</b>
Digital In HS	–	–	<b>X16</b>
Digital In	–	–	<b>X17</b>
Digital Out	–	–	<b>X18</b>
Relay Out	–	–	<b>X19</b>
Safety Relay	–	–	<b>X20</b>

Connectors in **bold** type: standard connector  
Other connectors: optional

**Tab. 5.2:** SWM7 connector assignments

### 5.5 Connection diagrams (Overview)




Figure 5.1: Connection diagram (Overview)

5.5.1 SWM7S-48/150




Figure 5.2: SWM7S-48/150 connectors

5.5.2 SWM7-48/150 with extended I/O




Figure 5.3: Connectors for SWM7-48/150 with extended I/O

**5.5.3 SWM7-48/100 (M6 motor connectors)**




Figure 5.4: Connectors for SWM7-48/100 (M6 motor connectors)

5.5.4 SWM7S-300/600




Figure 5.5: Connectors for SWM7S 300/600

**5.5.5 LWM7S (tbd)**

A drive version with a linear (non-switching) power stage is available in the same housing and with the same motor and control interface configurations as the SWM7. The LWM7S has excellent linearity around zero current, unsurpassed EMC- characteristics and no PWM- jitter.

It is ideal for critical applications in science and medicine as well as in semiconductor and magnetically sensitive environments, e.g. for positioning with sub-nanometer resolutions.

**5.6 Power supply (X5)**



There is a danger of electrical shock with serious personal injury if the servo controller isn't properly grounded. An isolating transformer is required for networks that are asymmetrically grounded or not grounded.




Figure 5.6: Power supply SWM7 (X5)

**5.7 Temperature supervision (X3)**




Figure 5.7: Temperature supervision (X3)



### 5.8 Enable and command interface (X1), (X2)

A hardware (HW) enable signal is not essentially needed. The HW enable signal can be parameterized to

- digital input 1 or 2
- SWM7 Test Box or (optional)
- "none".




Figure 5.8: Command interface (X2)




Figure 5.9: Enable interface (X1)

### 5.9 Motor (DC1, DC3) and brake connection (X4), (X3)

Connect the motor with the SWM7 unit see

- Fig. 5.7 and Fig. 5.8
- incl. the temperature supervision, see Fig. 5.4.

For the use of a holding brake, an external auxiliary supply according to the brake voltage has to be provided, see Fig. 5.9.




Figure 5.10: DC3 motor connection SWM7 (X4)




Figure 5.11: DC1 motor connection SWM7 (X4)




Figure 5.12: Motor brake (X3)

### 5.10 Feedback

Every closed servo system will normally require at least one feedback device for sending actual values from the motor to the servo drive.

Depending on the type of feedback device used, information will be fed back to the servo controller using digital and/or analog channels.

If necessary for the application, different sensor can be chosen for

- commutation
- speed control and/or
- positioning.

Commutation sensors for DC motors:

- usage of a brush-type motor there is no need for a commutation sensor
- for operation of brushless motors (DC3) a commutation sensor is required.

#### 5.10.1 Hall sensors (X13)

The servo controller of the SWM7 family provides interfaces for all common sensors on the market. The servo controllers are equipped with a high dynamic current loop with a superposed speed controller by default.

To close the current loop for electrical commutated servo motors (DC3) a commutation sensor is necessary.

Analogous to it a speed sensor to close the speed control loop for all servo motors must be employed.

The simplest sensor for that is a hall effect sensor. The connection of this type of sensor is depicted in Fig. 5.11.




Figure 5.13: Hall sensors (X13)



To ensure a smooth initial operation of a motor with hall effects it is necessary, that the switching edge of the sensors is phasing electrical angle to the motor.



If the HE sensors are inaccurately mounted switching errors are possible in the case of high velocity as well as in the case of high motor current. Please pay attention to the relation of the rotor magnets to the sensors while mounting cageless motors.

**5.10.2 Resolver (X9)**

The resolver is now accepted as the most robust commutation and position feedback device to support DC brushless motors. The SWM servo controller allows for the use of a 2 or multi-pole resolver.

The maximum achievable resolution with a resolver is 16 Bit.


A 2-pole resolver (1 electrical cycle per revolution) can deliver a position resolution of:

$$360^\circ / 65.536 = 0,0055^\circ (\cong 0,33' \text{ arc minutes})$$

Due to the limited „Tracking Rate“ of the Resolver/Digital converter used, the maximum achievable position resolution depends on the maximum speed.

The limits are (valid for a 2-pole resolver):

- 16 Bit for  $\leq 1.000$  rpm
- 14 Bit for  $\leq 4.000$  rpm
- 12 Bit for  $\leq 16.000$  rpm
- 10 Bit for  $\leq 64.000$  rpm.



**Figure 5.14:** Resolver (X9)

**5.10.3 Encoder differential (X12)**




Figure 5.15: Encoder differential

**5.10.4 Encoder unipolar (X12)**




Figure 5.16: Encoder unipolar

5.10.5 Sine Encoder with EnDat 2.2 (X11)




Figure 5.17: Encoder with EnDat

### 5.10.6 Netzer Encoder (X11)




Figure 5.18: Netzer Encoder

### 5.10.7 DC Tacho

The DC-Tachometer input is normalized for  $\pm 10V$  max. voltage input. The controller may be adapted to the signal level of the DC tacho by changing internal resistor values.

Details can be provided on request.




Figure 5.19: DC Tacho

### 5.10.8 TTL Encoder (general)

Many motor manufacturers supply servo motors with optical encoders with TTL-inputs. Depending on the application encoders with low (500...1.000 lines) or higher (up to 18.000 lines) resolution may be used.



Depending of the type of TTL incremental encoder the SWM servo controller allows connection of either differential or unipolar encoder signals.

The maximum permissible input frequency is 1MHz (4 MHz edge frequency). The maximum permissible velocity is thus

$$10^6 \cdot 60 / \text{Resolution}$$

For an encoder with 5.000 lines per revolution the motor can be operated up to a speed of 12.000 rpm.

**5.10.8.1 TTL Encoder (bipolar wiring)**




Figure 5.20: TTL Encoder (bipolar wiring)

**5.10.8.2 TTL Encoder (unipolar wiring)**






Figure 5.21: TTL Encoder (unipolar wiring)

**5.10.9 SIN/COS Encoder (X11)**



**Figure 5.22:** SIN/COS Encoder

**5.10.10 Tacho (X13)**



**Figure 5.23:** Tacho

**5.10.11 Sine Encoder with Hall (X13)**




Figure 5.24: Sine Encoder with Hall

**5.10.12 Encoder with BiSS (X11)**




Figure 5.25: Encoder with BiSS

**5.10.13 AMR-Encoder (X11)**




Figure 5.26: AMR- Encoder (X11)

**5.11 Analog and digital inputs and outputs**

These inputs and outputs are used mainly for customer specific applications and for troubleshooting (read out of error codes).

**5.11.1 Analog inputs and outputs**

**Inputs:** 2 different inputs (ANACMD1, 2) on the X2.

- The reference for the analog inputs is AGND (available at e.g. X2-1)
- Differential input range max  $\pm 10$  V
- Common mode range max  $\pm 13$  V
- Differential input resistance 20 kOhm
- Sampling rate  $\geq$  PWM frequency/sec.

**Outputs:** 3 analog outputs available (ANALOG OUT1, 2, 3) on the X2

- The reference for the analog outputs is AGND (available at e.g. X2-1)
- Output range is max  $\pm 10$ V
- Sink/source capability max 10 mA
- Update rate  $\geq$  PWM frequency/sec.

**5.11.2 Digital inputs and outputs**

Internally the digital inputs and outputs have its own grounds which are galvanically isolated from the other grounds.

To supply the digital I/O circuits two independent and isolated voltages are used and provided for external uses (+ 5V-DIGIN, + 5V-DIGOUT) as well. For simplicity the digital I/O grounds have a common ground point DIGIN-GND/DIGOUT-GND, which is available on X2-14 and X7-1.



Each of the digital supply voltages is capable of delivering up to 150 mA.

It's not allowed to connect it directly together – if higher current capability is needed use e.g. diodes for balancing.

The SWM7 has

- 5 digital inputs on X2 and X7:

No.	Connection front No.	Pin-No.	Hints
1	X2 DIGIN1	X2-13	1:1 CURRENT CONTROL switches between current and speed control if the SWM7 commanded externally (without PC or CAN)
2	X2 DIGIN2	X2-15	ENABLE serves as a hardware enable input
3	X7 DIGIN3	X7-3	can be configured for customer purposes
4	X7 DIGIN4	X7-4	
5	X7 DIGIN5	X7-5	

**Tab. 5.3:** SWM7 digital inputs

Properties of digital inputs:

- High level  $\geq 2.5V$
- Low level  $\leq 1V$
- Voltage range 0...24 V, recommended 0...5 V.
- Input resistance 4 kOhm.

- 6 digital outputs on X2:

No.	Connection front No.	Pin no	Hints
1	X2 DIGOUT1	X2-9	ERROR CODE F0 signals failure conditions to external circuits
2	X2 DIGOUT2	X2-10	ERROR CODE F1 signals failure conditions to external circuits
3	X2 DIGOUT3	X2-11	ERROR CODE F2 signals failure conditions to external circuits
4	X7 DIGOUT4	X7-7	can be configured for customer purposes
5	X7 DIGOUT5	X7-8	
6	X7 DIGOUT6	X7-9	

**Tab. 5.4:** SWM7 digital outputs

Properties of digital outputs:

- Error codes are actively driven TTL outputs
- DIGOUT4, 5, 6 are open collector outputs with max. 40 V, 80 mA.

### 5.12 RS-232 interface, PC connection (X2)

Operating, position control, and motion-block parameters can be set up by using the setup software on an ordinary commercial PC.



Connect the PC interface (X6) of the servo controller to a serial interface on the PC, while the supply to the equipment is switched off. This interface is galvanically isolated.




Figure 5.27: PC connection to SWM7

The interface is selected and set up in the setup software. Further details see on page 58.

### 5.13 CAN interface (X10)

This interface will be available in the next implementation.

The baud rate of the interface for connection to the CAN bus is configurable. The integrated CAN communication profiles are customer specific or MACCON standard.

The CAN-GND is isolated from other grounds and is the same for the second serial interface (User TXD/RXD). The analog setpoint inputs can still be used.




Figure 5.28: CAN connection to SWM7

### 5.14 Ethernet interface

Will be available as a special version in a next implementation.

---

**5.15 EtherCAT interface**

Will be available as a special version in a next implementation.

**5.16 USB interface (X3-1)**

Will be available as a special version in a next implementation.

## 6 Controller Monitoring with SetUp Tool SWM7.exe

This chapter describes the

- Installation of the setup software **SWM7 . EXE** for the SWM7S digital servo controller, see chap. 6.3.1
- Operational tasks, see chap. 6.4
- Menu items, see chap. 6.5.1
- Control windows in SWM7, see chap. 7.4.3 and
- Error messages, see in chap. 6.6 .

We offer training and familiarization courses on request.

### 6.1 General

The setup software is intended to be used for altering and saving the operating parameters for the SWM7 series of servo controllers.

There are two operational modes:

- Working in OFFLINE mode, see menu item “Service” → “Go Offline”, or in standalone mode, i.e. SWM7 unit disconnected.
  - This is useful for preparing different parameter files ( \* .macp- files) preconfigured for different motors, sensors, or speed settings.  
(i.e. enter setpoints in offline mode)  
To save use the menu item “File” → “Save as” <new name .macp> file.
  - The user can now upload in OFFLINE mode a specific <new name [1 . . . n] .macp>- file for the present hardware configuration, see menu item “Service” → “Go ONLINE”.
- Working in ONLINE mode you can choose the specific \*.macp- file for the specific hardware/motor/sensor configuration.

The attached servo controller can be set up and during this procedure the drive can be controlled directly by the service functions, see buttons “Enable Drive” and “Disable Drive”.



Only professional personnel who have the relevant expertise are permitted to carry out online parameter settings for a drive that is in operation.

In case of errors, hardware problems (e.g. fuses, connectors, capacitor reforming, user-specific settings etc.) or other service related questions contact MACCON tech support or phone +49 89 651220-0.

Sets of data that have been stored on data media are not safe against unintended alteration by other persons. Unexpected move could be the result if you use unchecked data. After loading a set of data you must therefore always check all parameters before enabling the servo controller.

The servo controllers must be adapted to the requirements of your machine. Usually you will not have to carry out this parameter setting yourself on the servo controller, but on a PC, with the assistance of the SWM7 setup software.

The PC is connected to the servo controller by a specific MACCON cable with RJ-11 connector (serial, see chap. 5.12). The setup software provides the communication between the PC and SWM7.

You can find the setup software on the accompanying CD-ROM and in the download area of our website, see MACCON download area.

With very little effort you can alter settings and instantly observe the effect on the drive, since there is a continuous (online) connection to the servo controller.



You can save sets of data (archiving)

- the parameter values in a \*.macp file
- the GUI layout of your SWM7 application without parameter values in a \*.mac file and load them again
- also print out the data sets.

On CD-ROM are stored motor-specific default sets of data for the most common combinations of servo controller and motor. In most applications you will be able to use these default values as a starting point to get your drive running.

## 6.2 Interfaces and Settings

The interfaces and settings are described in chap. 6.3.1.1 and chap. 6.3.1.2, and for troubleshooting see chap. 6.6.1.

## 6.3 Using the SWM7 SetUp tool

### 6.3.1 Installation of the software

#### 6.3.1.1 Hardware requirements

The serial interface (X2-1, RS-232) of the servo controller is galvanically isolated from internal circuits and is connected to the serial interface of the PC by a Sub-D, 9 pole to RJ-12 cable.

##### Communication interface:

If the PC is equipped with an RS-232 serial interface (COM port) you can connect via cable to the servo controller, otherwise use the USB-to-serial adapter.

#### 6.3.1.2 Installation under Windows OS

The CD-ROM contains

- the **SWM7.EXE** incl. graphical user interface (GUI)
- firmware for  $\mu$ C, DSP, FPGA, and
- optional customer specific parameter files.

Copy the complete directory with **SWM7.EXE** to your PC hard disk example C:\, D:\ or other free local drive.

You can create a quick link on your desktop or using an additional entry in Windows OS menu.

The **SWM7.EXE** file runs under Win2k, Windows XP, Vista, Windows 7 and Windows 8.

##### 6.3.1.2.1 Genuine RS-232 interface

If you starts the **SWM7.EXE** software for the first time, you have to select the serial interface, see Fig. 6.2.

##### 6.3.1.2.2 USB-to-serial adapter

Install the drivers for the USB-to-serial adapter, see description on manufacturer's CD-ROM.

Check in the Windows Device Manager that the COM port is preset and note the COM port number. Set the proper COM port – see under “Settings” → “Com port”. Otherwise you must update the COM port in your Windows OS system, see chap. 6.6.1.

#### 6.3.1.3 Installation under Linux OS

Not possible.

## 6.3.2 Putting into operation

### 6.3.2.1 Standby operation without connected motor

In this mode you can

- check the proper function between PC and connected/switched on SWM7
- prepare specific sets of \* .macp- files for your HW configuration (drive, sensors, resolvers, encoders or ext. controls)
- prepare specific sets of \* .mac- files for GUI layouts in accordance to your present HW configuration and use cases for operation.

You need this information

- concerning the drive components:
  - rated mains supply voltage
  - motor type (motor data, if the motor type is not listed in the motor database – then contact MACCON tech support)
  - feedback unit built into the motor (type, poles, lines, protocol etc.)
  - moment of inertia of the load.
- Documents, User Manual and access to MACCON tech support via internet
  - User Manual – this manual
  - Accessories manual
  - CAN communication protocol description (optional).

#### Procedure:

1. Before attempting to install, service or maintain this unit always read the manual and the specific safety instructions first.
2. Unpack servo controller and accessories and mount the servo controller as described on page 31.
3. Connect the servo controller as described in chap. 5.5 for minimum wiring **without** connected drive.
4. Install the software, see chap. 6.3.1 .
5. Connect the interface cable (COM port of PC and (X2-1) of the servo controller).

USB to serial converter can be used if no COM port is available.

Note: An USB interface will be available as a next implementation.

6. Switch on auxiliary power supply for the servo controller.
7. Double-click the SWM7 . EXE icon on your Windows desktop – the MACCON SWM7 SETUP program opens, see below:




Figure 6.1: MACCON SWM7 SETUP main window (example)



Wait until the question marks and/or the blue progress bar are gone – then the communication process via the interface to SWM7 is finished.

- If the communication is started for the first time, you have to setup the communication parameters.  
Choose the communication system and the interface, where the servo controller is connected to, see below:




Figure 6.2: Choose Serial Port (example COM3)

- If the communication well established, you will see a blue progress bar in the status line of the SWM window. Wait until this upload is finished. If OK, then in the message window will display the current SWM7 software version, see below.




Figure 6.3: SWM Message window (example no error)

- In case of errors you will see an error message – example text added in red.  
To maintain any error message, see chap. 6.6 .
- For operational task, see chap. 6.4 .

**6.3.2.2 Operation with connected drive**

Connect the drive to (X4), see chap. 5.5.

Using the buttons “Enable” or “Disable” the drive will be gone into operation.

**6.3.3 Guide for setup**

Follow the instructions given by MACCON tech support. Details for firmware update and specific setups are described in chap. 6.5.1.4 , see on page 65.

Restoring the default values is written in 6.4.7 .

**6.4 Operational tasks**

This chapter describes the possibilities for using the SWM7 software.



The SWM7 GUI is formatted to distinguish the setup parameters for

- common applications (standard user)
- advanced user and
- insider or MACCON tech support,

see details in chap. 6.4.3.1 and chap. 6.4.3.2 , both on page 62.

The display for parameter and measuring values is divided into the following, see Tab. 6.1:

Window name	Example	Remarks
Parameter display		Using the “+” and “-” keys you can adjust the desired parameter value.
		Use or not use parameter “Index Pulse”
Measuring display		Display “Abs. Position” is valid. green = valid
		Display “Pwm Frequency (FPGA)” is TBD . yellow = TBD
		Measuring display: “Index Pulse” not used grey = not used red = TBD
		Display “FPGA Status Flags 2” grey = not used green = used/activ

Window name	Example	Remarks
Selection window		In this selection window you can choose using the radio buttons one of the displayed item.
		Direction "not inverted" or "inverted"

Tab. 6.1: Definitions for display of parameter, measuring and selection windows

#### 6.4.1 Loading/Saving a Parameter Value Set

An existing parameter value set can be opened using "File" → "Load Parameters". Parameters values are downloaded automatically to the SWM and have immediate effect.

All parameter changes are discarded at power-off unless saved to flash using the "Write-to-Flash" button, see in right pane.




Figure 6.4: "Write Parameters to Flash" button

As the parameters in the setup tool are always up-to-date when connected to a device, no upload is necessary before saving to disk, see menu item "File" → "Save Parameters as" <file\_name.macp>, i.e. your "personnel" stored file.

#### 6.4.2 Enable drive/Disable drive

Use the button "Enable Drive", see Fig. 6.5, page 61, to monitor all settings in any parameter/measuring window in practice.

For more details, e.g. optimizing the different drive settings see chap. 7.




Figure 6.5: "Enable Drive" and "Disable Drive"

#### 6.4.3 Adding parameter displays to a page

The menu item "Parameters" opens a window which allows selecting additional parameters for display. Simply move the desired parameter to the certain setup page by drag-and-drop, see below:




Figure 6.6: Adding parameter “Profile: Max. Acceleration” to a section (example)

The parameters can be used simultaneously in several tabs of the GUI.

6.4.3.1 Meaning of formatting in the “Parameters” window

In Fig. 6.6 are displayed different format settings:

- **bold** these parameters are used for common tasks, i.e. for **standard users**
- normal for advanced users
- *italic* for *insider* (User class = Debug) and *MACCON tech support*.

The user classes are visible in the info box, see Fig. 6.6.

6.4.3.2 Meaning of formatting in a parameter display

The following formats are used/visible in each control window:

Frame	Title in	parameter/measuring for:
bold	bold	common applications (standard user)
bold	normal	advanced user
thin	normal	insider or MACCON tech support

6.4.4 Delete parameter display of a page

You can delete parameters in a section. Choose in menu item “Service” → “Modify”. Then select the control window, e.g. “Encoder Offset (circular)” in Fig. 6.6 and right-click the mouse to delete.




Figure 6.7: Delete measuring window “Profile State” (example)

Confirm message “Are you sure to delete” with “OK” button.

The measuring window “Profile State” is deleted now.

### 6.4.5 Creating user-defined tabs

You have the ability to create your own tabs (parameter page(s)) for controlling and monitoring your drive system. Choose in menu item “Service” ⇒ “Modify”.

Then right-click on a **free area in the tool bar** to open the context menu, see Fig. 6.7.




Figure 6.8: "Add Sheet" option

Click on “Add Sheet” and enter a user-specific name for this window e.g. “Voltages”.




Figure 6.9: Create caption "Voltages" (example)

Confirm with “OK” to create the new tab.

Then you can add your user-specific control windows, see chap. 6.4.3 , page 61.

At least you need to save your new GUI in the \*.mac- file, see menu item “File” ⇒ “Save”.

### 6.4.6 Deleting user-defined tabs

You can delete your own tabs (parameter page(s)). First choose in menu item “Service” ⇒ “Modify”.

Then right-click on the tab e.g. “VOLTAGE” to be deleted and select “Remove Sheet”.




Figure 6.10: “Remove Sheet” selection

At least you need to save your new GUI in the \*.mac- file, see menu item “File” ⇒ “Save”.

**NOTE:** In case of errors you can fall back, see chap. 6.4.7 below.

### 6.4.7 Restoring default GUI layout

For restoring the default values you need

- CD-ROM contains the GUI layout file for your customer specific project in the following naming: SWM7 <Name of customer or project>.mac  
**Example:** SWM7\_MACCON\_01.mac

Then locate on your hard disk the \*.mac- file. Overwrite this file with the CD-ROM's. This generates the "Delivery Status" of your project.

For all other fall-back procedures contact MACCON tech support.

## 6.5 Description of menus and windows

### 6.5.1 Menu items

The menu items are described in the following. You can open the menu items using

- the mouse pointer or
- <ALT> key followed by the underlined letter e.g. <ALT+f> to open the "File" menu.

#### 6.5.1.1 File menu

Menu item	Description	<ALT+f>
<b>New</b> .....	Create a blank parameter window "Page1" with a MACCON configuration file name "Untitled0.mac"	<ALT+f+n>
<b>Open</b> .....	Opens a window for selection of a MACCON configuration file *.mac	<ALT+f+o>
<b>Save as</b> .....	Opens a window for - saving a new file (i.e. overwrite Untitled0.mac) or - overwrite the present configuration *.mac file.	<ALT+f+a>
<b>Load Parameters</b> .....	Loads a parameter value file *.macp	<ALT+f+p>
<b>Save Parameters as</b> ....	To save/overwrite a parameter value file *.macp	<ALT+f+v>
<b>Examine Parameter file</b> .....	Examines the MACCON parameter file *.macp in relation to the FW and displays all present parameter values in the "Parameter Preview" window.  You can export these values in a *.csv- or *.txt file.	<ALT+f+m>
<b>Exit</b> .....	Close the program and ask to save or not.	<ALT+f+e>

#### 6.5.1.2 Settings tab


COM port selection for genuine COM ports and USB-to-serial adapters.

#### 6.5.1.3 Parameters tab

The user can select any additional control windows or tab, see in chap. 6.4.3 and chap. 6.4.5 .



**6.5.1.4 Service menu**

Menu item	Description	<ALT+e>
<b>Modify</b> .....	If selected (active) “✓Modify” you can alter – the position of any parameter/measuring and/or – add additional parameters or tab sheets. Save the new settings in your “personnel GUI” parameter * .mac file.	<ALT+e+m>
<b>Go Offline</b> .....	Disables communication (for MACCON tech support)	<ALT+e+o>
<b>Show Communication</b>	Displays in the “Telegram” window the running communication. You can “Stop” or “Pause” logging or “Delete” the communication log.	<ALT+e+s>
<b>Show Database</b> .....	Displays the internal data base of controller parameters.	<ALT+e+d>
<b>Re-read Parameters</b> .....	Re-read the parameter from the connected SWM7, see SWM Message window on page 59.	<ALT+e+r>
<b>Firmware Update Tool</b> ...	Opens a “Firmware Maintenance” window.	<ALT+e+u>
	 Permitted only with the express permission of MACCON tech support!	
<b>Upload Controller Flash</b>	Upload controller data into a file for MACCON tech support.	<ALT+e+L>
<b>Show Groups</b> .....	Displays parameter groups, used by MACCON tech support.	<ALT+e+g>

**6.5.1.5 Type Plate tab**

Displays (and modify) the type plate data stored in the drive (will be used in a next version).

**6.5.1.6 About tab**

Displays the current software version.

**6.5.2 Related files (GUI layout \*.mac, parameter file \*.macp)**

The SWM7 Setup tool will work as a single file without installation procedure. The software can be operated directly out of your hard disk working directory.

There are two file types related with SWM7 software:

1. MACCON GUI layout file (\* .mac) contains  
– the specific set of parameter sheets (tabs) and the parameter layout.  
The menu items “File” ⇨ “Open” and “Save” are related to <name .mac> files.  
On software startup, the last used MAC file is loaded.

2. MACCON parameter file (\* .macp )  
This file contains the values of all parameters for a certain drive setup and is independent of the layout file.

It is used as back-up or to duplicate drive configurations.

The menu items “File” ⇨ “Load Parameters” and “Save Parameters” are related to \* .macp files.

The connection between PC and SWM7 device is established via RS-232 link to X2 connector. The matching cable is delivered with your device.

The COM port can be selected in the “Settings” menu.

## 6.6 Error Messages

This chap. describes some error messages in the status line of the SWM7 GUI.

### 6.6.1 Handling of RS-232 communication errors

#### 6.6.1.1 Message “Transmitting Telegram: No Response”

Indicates that the SWM7 unit is not responding. Check power supply, cabling and COM port setting.

#### 6.6.1.2 Message “COM Error 0x02”

If you use a build-in COM port and frequently get an error message like “COM Error 0x02” in the status line of SWM7 program, it is necessary to change the serial port setting. (This applies to communication chips of type 16C550)

#### Changing the serial port setting:

1. Open the Windows device manager and select the used COM port e.g. COM1.




Figure 6.11: Windows “Device Manager” window

2. Then display the properties of the COM port used and click “Advanced” button.





Figure 6.12: Port Settings for the COM port (default)

3. Reduce settings for receive buffer to **(4)**.



**Figure 6.13:** Adjust Receive Buffer for COM port

4. Click “OK” to close all device manager windows.
5. **Restart Windows** to make these changes become effective.

Now the warnings should not show up anymore.

## 6.6.2 Errors regarding wrong setup in SWM7 GUI

This chapter shows some examples for wrong system setup in SWM7 GUI.

The error messages are cleared as soon as the setup is adjusted properly.

### 6.6.2.1 Invalid combination of feedback sensors

Due to hardware restrictions, some combinations of feedback sensors are not possible.

E.g., you can not use “Sine encoder 2” and “Endat” at the same time. In case of invalid sensor settings, one of the following error messages is output, see Fig. 6.9:

- “Duplicate Use Of Encoder Input 1”
- “Duplicate Use Of Encoder Input 2”, or
- “Resolver disables Encoder Input 2”.




**Figure 6.14:** Duplicate Use Of Encoder Input 2

### 6.6.2.2 Missing motion sensors

Additionally, the missing sensor is mentioned in the message window, see Fig. 6.8:

- “No Commutation Sensor defined”
- “No Speed Sensor defined”, or
- “No Positioning Sensor defined”.



**Figure 6.15:** Missing Motion Sensors

### 6.6.2.3 Incomplete sensor definitions

Some sensors need additional configuration, e. g. if you select “Hall sensors” as feedback sensor you also have to define the hall switch type (supply voltage).

Otherwise, an error message is output:



Figure 6.16: No Hall Sensor Type defined

### 6.6.3 Runtime Errors

Runtime errors appear during operation, if a safety limit is reached. In this case, the drive will be disabled immediately. The error message is cleared if the cause of the error is removed and the drive is disabled and re-enabled by the user.


#### 6.6.3.1 Over Voltage

The message “Over Voltage” appears, if the actual bus voltage exceeds the allowed maximum, see Fig. 6.1.



Figure 6.17: Over voltage

This may also be caused by a wrong setting of parameter “Max. Bus Voltage” in tab. “DATA AQUISITION”:



Standard value = 80 V



0 V = Wrong setting, will result an error message

#### 6.6.3.2 Under Voltage

This error indicates that the *internal* SWM7 voltage is under limit.

#### 6.6.3.3 Over Current

This message indicates, that the *motor current* is over the limitation.

#### 6.6.3.4 Over temperature heat sink


This messages indicates, that the heat sink temperature is over the limit of the used sensor.



Figure 6.18: Over temperature heat sink

**Example:**

Limitation to 130° C for this type of sensor.




#### 6.6.3.5 Error on resolver

Error in resolver function, check cabling and/or resolver.

**6.6.3.6 I\*t warning**

The error comes up, if in the tab “SPPED / CURRENT CONTROL” the I\*t limit was set to 20 % of Ipeak and this value has been exceeded, but lower then max. current in parameter display window ”Max. Current, see 6.4.



**Figure 6.19:** I\*t warning

**6.6.3.7 I\*t error**

The I\*t current is higher then the max. current, see see 6.4.

The SWM7 unit turns off automatically.

**6.6.4 Other error messages related to SWM7 program**

In the case of specific errors displayed in the status line – then contact MACCON tech support.



Opening the device means loss of warranty!

## 7 System Parameters Setup **\_TBD\_**



The complete chapter 7 is in editorial status “**Start-up**” and “**Not tested**”.

You can use this chapter for a first information only.

This User Manual describes the operational tasks for the SWM7 series of digital servo controllers.



Pay attention to the Safety Instructions, to avoid any risk for dangerous voltages, temperatures and hardware damage.

All the software and User Manual required for the operation of SWM7 is electronically available on CD-ROM and if necessary in paper form also.



First check the chap. 7.9 ,Trouble Shooting on page 123.

In case of errors, hardware problems (e.g. fuses, connectors, user-specific settings etc.) or other service related questions contact MACCON tech support.

### 7.1 How to use the User Manual

For details see chap. 1.1 .

#### 7.1.1 Target group

Only qualified personnel are permitted to perform activities such as transportation, installation, commissioning and maintenance.

The SWM7 GUI allows a distinction according to different use tasks, for details see in chap. 6.4.3.1 and 6.4.3.2.

### 7.2 Motor Definitions

MACCON delivers a complete configured SWM7 software adjusted for the present motor and use cases. If needed, the user can change/apply e.g. new feedback hardware or change interfaces.

In this case and also for fine tuning the user can apply the SWM7 software for adjusting.



If

- changing the motor or other hardware written in the project sheet or
- errors, hardware problems (e.g. fuses, connectors, capacitor reforming, user-specific settings etc.) or other service related questions contact MACCON tech support or phone +49 89 651220-0.

### 7.3 Speed and Current definition (Setup)

#### 7.3.1 Current Loop

An optimum matching of the current controllers to the motor ensures good torque control and a good servo response. This also reduces losses in the motor.

The current loop is optimized by adjusting mainly the Current Control P gain, I gain and D gain.



Depending on the customer specific firmware version the D gain is not present in the SWM7 software.

### 7.3.1.1 Current control P gain / I gain / D gain

In SWM7 a PID controller calculates an error value as the difference between a measured process variable and a desired setpoint, i. e. in a control loop feedback mechanism, see Fig. 7.1.




Figure 7.1: PID Control system

The PID variables are:

Term/name	Explanation
Error term	The error term is derived by subtracting the feedback (motor speed) from the set point (set speed). This is the error in terms of a number of encoder counts per unit time.
Proportional term	Simple proportional coefficient $K_p$ is multiplied by the error term. Provides linear response to the error term.
Integral term	Integral coefficient $K_i$ is multiplied by the error term and added to the sum of all previous integral terms. Provides response to accumulated error.
Derivate term	Derivative coefficient $K_d$ is multiplied by the difference between the previous error and the current error. Responds to change in error from one PID cycle to the next.

Tab. 7.1: PID variables


The PID algorithm for control does not guarantee an optimal control of the system or system stability. The following factors to consider using the SWM7 software:  
(values are example only)

- PID cycling time (0.3 sec)  
– Motor speed (150 rpm)

- Encoder resolution (1.000/rev.)
- PWM frequency (15 kHz)
- Interrupt driven PID trigger
  - eliminates code tuning
  - maintains accurate PID timing
- Integral windup
- PWM term overflow
- PID variable overflow

How are these coefficients for P, I and D determined?

The behavior of most systems is measured by the system's "Step response", see Fig. 7.2.



**Figure 7.2:** Display of response on a 2-channel oscilloscope (insert original screenshot ??)

TBD text\_text\_text



**PID TESTING - P=5, I=0.001, D= 1 TO 5**




Figure 7.3: PID testing

**Parameter identification by optimization of current step response:**

This practical method of establishing current controller parameters by step-response optimization of motor current involves the following steps:

- Operate the motor in current control.
- Connect a signal generator to the command input (using the Test box - optional)
- Set frequency to around 100...500 Hz, amplitude corresponding to 50...100 % of motor current.
- Measure the current in a motor phase with a current probe or by using an analog output.
- View the commanded and the actual motor current on a 2-channel oscilloscope.

Adjust the response of the actual motor current by changing the current controller parameters.



Care should be taken that the motor shaft does not move.  
If necessary, increase signal frequency or reduce amplitude.

A good setup sequence to optimize the current control response is:

- Set I- component of current controller to 0 dB (nearly zero integral gain)
- Increase P-component of current controller gain until the current starts to oscillate
- Halve the value of the P-gain
- Measure the current in a motor phase with a current probe or by using an analog output.
- Again increase the I-component until the current begins to oscillate.
- Halve this value of I-gain.

- Store the optimum current controller values established in Flash memory.

*Max. Current*

Provides a current limit for all operating modes based on the maximum current of the drive.

Reduce this value to a level according to your motor.

*Commutation Sensor Select*

Defines the feedback system which is used for phase and current control.

It may be the same as speed and position sensor.

*I\*t Limit*

I\*t monitoring limit for creating a warning or error.

### 7.3.2 Speed Loop

It is necessary to match the servo controller to the mechanics of the drive system in order to optimize performance in the velocity control mode.

#### 7.3.2.1 Speed control P gain / I gain / D gain

This practical method of establishing controller parameters by step-response optimization of motor velocity involves the following steps:

##### Parameter identification by optimization of velocity step response:

- Motor is operated in the velocity control mode
- Connect a frequency generator to the control input (possibly using TBD ???)
- Adjust frequency to around 0.5...10 Hz
- Adjust the amplitude initially to around 10 % of nominal velocity
- View the command and the actual motor velocities on a 2-channel oscilloscope (analog output)
- Adjust motor velocity response by changing the velocity controller parameters
- Increase the amplitude of the command signal in stages to nominal.
- Check and correct velocity control parameters, if necessary
- Store the established parameters in Flash memory.

#### 7.3.2.2 Speed: Max. Acceleration / Deceleration

Specify the limits for speed profile operating mode.

#### 7.3.2.3 Speed: Ramp

Activates the speed profile operating mode, which limits acceleration and deceleration ramps of the (external) speed command.

#### 7.3.2.4 Speed: Max. Acceleration / Deceleration

Specify the limits for speed profile operating mode.

#### 7.3.2.5 Tach Lowpass, MAF

Sets number of taps (and cut-off frequency) of the moving-average lowpass for speed sensors (not effective for hall sensors or DC tach).


In case of resolver operation the lowpass has to be configured according to the Tab. 7.1:

		PWM frequency (kHz)					
		15	20	25	30	40	50
Resolver frequency (kHz)		Lowest filter value, or a multiple					
	10	6	8	10	6	8	10
	8	15	10	25	15	10	25
	6.6666	18	24	30	18	24	30
	5	12	16	20	12	16	20

**Tab. 7.2:** Lowpass configuration values for resolver operation

### 7.3.2.6 Tach Lowpass, PT1

The Fig. 7.4 shows the PT1 filter for smoothing the speed loop reaction.



**Figure 7.4:** Parameter "Tach Lowpass, PT1"

## 7.4 Display Information on SWM7 GUI

### 7.4.1 Examine parameters file

Shows the parameter values stored in a \*.macp file.

Choose in menu item "File" → "Examine Parameter file...", and select a \*.macp file. The result is shown in Fig. 7.5 below:




Figure 7.5: "Parameter Preview" window

**Result:**

- in column "Found" will be displayed "YES", if the parameter found in SWM firmware
- the column "M/P" informs the user, which parameter is
  - (read/write) = P
  - (read- only) = M.

Using the export function in a \*.csv and/or \*.txt file, you have more possibilities for searching any parameter, caption or value incl. to compare two different \*.macp files.

**7.4.2 Parameter window or measuring window marked in red**

In case that the current firmware does not contain a specific parameter which is part of the current GUI layout, see Fig. 7.3 - this window is marked as "Not valid".



Figure 7.6: "CAN Transmit Mode" not present in current firmware

**7.4.3 SWM7 control windows**

In this chapter are described all control windows of the SWM7 GUI, see

- Control windows in "POSITION CONTROL" tab, page 77
- Control windows in "SENSORLESS CONTROL" tab, page 79
- Control windows in "FIELD WEAKENING" tab (TBD), page 81,
- Control windows in "PHASE FINDING" tab, page 83,
- Control windows in "CAN" tab, page 85,
- Control windows in "OFFSET" tab, page 87
- Control windows in "MOTION SENSOR MONITORING" tab, page 89,
- Control windows in "SPEED / CURRENT CONTROL" tab, page 93,
- Control windows in "MOTION SENSORS" tab, page 97,
- Control windows in "SYSTEM SETUP" tab, page 101,
- Control windows in "SWM STATUS" tab, page 102,
- Control windows in "DATA ACQUISITION" tab, page 105,

- Control windows in "COMMAND INPUT SELECT" tab, page 110,
- Control windows in "ANALOG INPUT" tab, page 112.









All control windows listed in alphabetic sequence, also sorted in Index of this User Manual.



Depending on the SWM7 configuration and firmware version supplied are not all control windows present, or may be arranged differently.

You can configure the GUI tabs and control windows acc. your needs, see chap. 6.4.3 to 6.4.6 .





**7.4.3.1 Control windows in "POSITION CONTROL" tab**

POSITION CONTROL	Control window (in alphabetic order)	Explanation <i>Input values</i>
		<p>Abs. Circular Position</p> <p>Displays the circular position of the motor.</p> <p>None</p>
		<p>Abs. Position</p> <p>Displays the current position of the motor.</p> <p>None</p>
		<p>Abs. Position Valid</p> <p>Display the validity of the position, i.e. Abs. Position is inside range.</p> <p>Display Valid or Not valid</p>
		<p>Encoder Offset (circular)</p> <p>Adjust the offset of the connected encoder.</p> <p>-----Input values-----</p>
	<p>POSITION CONTROL</p> 	<p>Index Position</p> <p>Displays the index position.</p> <p>None</p>
		<p>Index Pulse</p> <p>Selection for "Use Index Pulse" for commutation.</p> <p>Choose Use or not used.</p>
		<p>Internal Target Position</p> <p>Displays the internal target position of profile generator.</p> <p>None</p>
	<p>POSITION CONTROL</p> 	<p>Position</p> <p>Displays the current position.</p> <p>None</p>
		<p>Position Control: D Gain</p> <p>Set a position control D gain for</p>

**POSITION CONTROL**

Control window (in alphabetic order)	Explanation <i>Input values</i>
	systems with fast load changes.
	Position Control: Feed Fwd  Additional control parameter for optimized response and low following error.
	Position Control: Max. Speed  General speed limit for position profile mode.
	Position Control: P gain  The position control loop is mainly adjusted via this proportional gain.
	Position Control: Speed Command  Speed command resulting from position profile generator.
	Position Sensor Select  Defines the feedback system which is used for position control loop.  <i>Display only.</i>
	Profile State  State of profile generator  <i>Display only.</i>
	Profile: Max. Acceleration  Specifies the limits for position profile operating mode.
	Profile: Max. Deceleration  Specifies the limits for position profile operating mode.
	Profile: Max. Speed  Specifies the limits for position profile




**POSITION CONTROL**

<b>POSITION CONTROL</b>	<b>Control window</b> (in alphabetic order)	<b>Explanation</b> <i>Input values</i>
		operating mode.
		Profile: Position Command
		Profile: Speed Command Speed setpoint for sensorless control in speed mode.
<b>POSITION CONTROL</b>		Target Position Target position of the profile generator
		Use Index Pulse Displays state of index pulse. Displays Index Pulse Used, if "Use Index Pulse" was selected.

Tab. 7.3: Control windows in "POSITION CONTROL" tab

**7.4.3.2 Control windows in "SENSORLESS CONTROL" tab**

For sensorless (open loop) motor control, the relevant settings can be made here. Usually you receive by MACCON a customized and validated parameter set for your sensorless application.

<b>SENSORLESS CONTROL</b>	<b>Control window</b> (in alphabetic order)	<b>Explanation</b> <i>Input values</i>
		Acceleration Speed ramp for closed loop continuation of speed ramp.
		Acceleration uncontrolled Speed ramp for open-loop startup.
		Alignment Delay Time for changing parameters from open to closed loop control.
		Amplitude D Gain D gain of PD sensorless current controller in speed mode.

SENSORLESS CONTROL	Control window (in alphabetic order)	Explanation <i>Input values</i>
		Amplitude P Gain P gain of PD sensorless current controller in speed mode
		Current Control
		Desired Phase Angle The desired phase angle has to be optimized between high torque and a stable operating point. A setting of 20° ...30° el. phase angle is suggested.
SENSORLESS CONTROL		Freq. Adjust Gain P gain for motor frequency control.
		Max. uncontrolled Speed Maximum speed for open-loop startup.
		Minimal Current Set the minimal current. <i>Setting for sensorless control.</i>
		Observer Low Pass Logarithmic setting of position observer gain. Each +1 digit doubles the time constant. <i>Use -4 as start value for small, low inertia motors.</i>
		PC: Speed Command Speed setpoint via PC for sensorless control in speed mode.
SENSORLESS CONTROL		Phase Adjust Gain P gain for phase angle control (controlled operation)



<b>SENSORLESS CONTROL</b>	<b>Control window</b> (in alphabetic order)	<b>Explanation</b> <i>Input values</i>
	<div style="border: 1px solid black; padding: 5px;"> <p style="margin: 0;"><b>&lt;2&gt; Ramp Time</b></p> <div style="display: flex; align-items: center;"> <div style="writing-mode: vertical-rl; transform: rotate(180deg); font-size: 8px; margin-right: 5px;">SLEESS</div> <div style="border: 1px solid black; padding: 2px;"> <div style="display: flex; justify-content: space-between; width: 100%;"> <span>++ ++ ++ ++</span> </div> <div style="text-align: center; font-size: 1.2em;">0.0000 sec</div> <div style="display: flex; justify-content: space-between; width: 100%;"> <span>-- -- -- --</span> </div> </div> </div> </div>	<p>Ramp Time</p> <p>Current ramp time for motor alignment.</p>
	<div style="border: 1px solid black; padding: 5px;"> <p style="margin: 0;"><b>&lt;2&gt; S/L Current Amplitude</b></p> <div style="display: flex; align-items: center;"> <div style="writing-mode: vertical-rl; transform: rotate(180deg); font-size: 8px; margin-right: 5px;">SLEESS</div> <div style="border: 1px solid black; padding: 2px;"> <div style="text-align: center; font-size: 1.2em;">+ 0.0000 %</div> </div> </div> </div>	<p>S/L Current Amplitude</p> <p>Monitoring values for optimizing sensorless control.</p>
	<div style="border: 1px solid black; padding: 5px;"> <p style="margin: 0;"><b>&lt;2&gt; S/L Freq. Correction</b></p> <div style="display: flex; align-items: center;"> <div style="writing-mode: vertical-rl; transform: rotate(180deg); font-size: 8px; margin-right: 5px;">SLEESS</div> <div style="border: 1px solid black; padding: 2px;"> <div style="text-align: center; font-size: 1.2em;">+ 0.0000 mHz/s</div> </div> </div> </div>	<p>S/L Freq. Correction</p> <p>Monitoring values for optimizing sensorless control.</p>
	<div style="border: 1px solid black; padding: 5px;"> <p style="margin: 0;"><b>&lt;2&gt; S/L Phase Angle Error</b></p> <div style="display: flex; align-items: center;"> <div style="writing-mode: vertical-rl; transform: rotate(180deg); font-size: 8px; margin-right: 5px;">SLEESS</div> <div style="border: 1px solid black; padding: 2px;"> <div style="text-align: center; font-size: 1.2em;">+ 0.0000 °el</div> </div> </div> </div>	<p>S/L Phase Angle Error</p> <p>Monitoring values for optimizing sensorless control.</p>
	<div style="border: 1px solid black; padding: 5px;"> <p style="margin: 0;"><b>&lt;2&gt; S/L Phase Correction</b></p> <div style="display: flex; align-items: center;"> <div style="writing-mode: vertical-rl; transform: rotate(180deg); font-size: 8px; margin-right: 5px;">SLEESS</div> <div style="border: 1px solid black; padding: 2px;"> <div style="text-align: center; font-size: 1.2em;">+ 0.0000 °el</div> </div> </div> </div>	<p>S/L Phase Correction</p> <p>Monitoring values for optimizing sensorless control.</p>
<b>SENSORLESS CONTROL</b>	<div style="border: 1px solid black; padding: 5px;"> <p style="margin: 0;"><b>&lt;2&gt; Start Current (DC)</b></p> <div style="display: flex; align-items: center;"> <div style="writing-mode: vertical-rl; transform: rotate(180deg); font-size: 8px; margin-right: 5px;">SLEESS</div> <div style="border: 1px solid black; padding: 2px;"> <div style="display: flex; justify-content: space-between; width: 100%;"> <span>++ ++</span> </div> <div style="text-align: center; font-size: 1.2em;">0.0 %</div> <div style="display: flex; justify-content: space-between; width: 100%;"> <span>-- --</span> </div> </div> </div> </div>	<p>Start Current (DC)</p> <p>Initial current for motor alignment</p> <p><i>Suggested start value 5 %</i></p>

**Tab. 7.4:** Control windows in "SENSORLESS CONTROL" tab

### 7.4.3.3 Control windows in "FIELD WEAKENING" tab (TBD)

The necessary parameters for field weakening operation can be controlled in this section.

This settings in "FIELD WEAKENING" tab can be used to drive a motor at a higher speed than nominal for a given DC supply voltage with reduced torque.

The field weakening effect is achieved by influencing the ID and IQ current vectors.

FIELD WEAKENING	Control window (in alphabetic order)	Explanation <i>Input values</i>
		Current Command D Display of actual current loop command (D vector) <i>D vector resulting from speed controller.</i>
		Current Command Q Display of actual current loop command (Q vector) <i>Q vector resulting from speed controller.</i>
		Current D Display of actual motor current (D vector) <i>D vector of measured motor current</i>
		Current Q Display of actual motor current (Q vector) <i>Q vector of measured motor current</i>
FIELD WEAKENING		Estimated Back EMF Back EMF as estimated by operation point and motor data. <i>RMS value of single phase equivalent circuit</i>
		Field Weakening Mode Auto field weakening mode selection. <i>IQ=const: IQ=commanded current, ID is set by algorithm</i> <i>Imot=const: current magnitude = commanded current; ratio between IQ and ID set by algorithm</i>
		Max. Current Choose the max. current. <i>Example:</i> <i>If the ext. PSU supplies 5 A, then the selector enables to choose between 0...5 A.</i>
FIELD WEAKENING		Max. Current Angle Choose the max. current angle. <i>Only relevant for auto field weakening mode.</i>
		Max. Reactive Current

FIELD WEAKENING	Control window (in alphabetic order)	Explanation <i>Input values</i>
		Limitation of Reactive Current vector based on the "Current ADC range" of the motor.  <i>Current limitation setting (D vector)</i>

Tab. 7.5: Control windows in "FIELD WEAKENING" tab

#### 7.4.3.4 Control windows in "PHASE FINDING" tab

A phase finding cycle is necessary to determine the actual rotor position to apply the correct motor currents.

For non-absolute feedback systems, phase finding is required after each power-up.

Choose "PHASE FINDING" tab when

- no hall sensors and
- no absolute encoder or resolver are present.

After first enabling, the phase finding result can be used until power-off. The phase finding can anyway be performed on each enabling.

The parameters may be optimized to achieve a smoother or shorter phase finding cycle. If current values are too low or selected times are too short the convergence quality will get lower.

Phase finding should result in a quality level of more than 90%.

Phase Finding	Control window (in alphabetic order)	Explanation <i>Input values</i>
		Coarse Tuning Gain  Amplitude for coarse tuning cycle.
		Coarse Tuning Time  <i>Suggested start value: 1000 ms</i>
		Communication angle (manual)  Can be adjusted manually for special requirements  <i>Is set by the phase finding algorithm.</i>
		Convergence Error  Displays the convergence error  <i>The smaller the error, the better the convergence quality.</i>
Phase Finding		Convergence Quality  Result of phase finding algorithm.  <i>Should be more than 90 %.</i>

Phase Finding	Control window (in alphabetic order)	Explanation <i>Input values</i>	
		El. Angle Offset Electrical angle between motor phase and sensor orientation. <i>Display only</i>	
		Fine Tuning Gain Control loop gain for fine tuning cycle	
		Fine Tuning Time Duration of fine tuning cycle <i>Suggested start value: 1000 ms</i>	
	<p>After first enabling, the phase finding result can be used until power-off. The phase finding can anyway be performed on each enabling.</p>	Motor Startup Synchronization Choose “Phase Finding” when – no hall sensors and – no absolute encoder or resolver are present. The parameters may be optimized to achieve a smoother or shorter phase finding cycle. If current values are too low or selected times are too short the convergence quality will get lower. <i>Phase finding should result in a quality level of more than 90%.</i>	
	Phase Finding		Phase Finding Flags Indicates state of running or finished phase finding algorithm. <i>Display only.</i>
		Pulse Time Duration of current pulses applied during coarse tuning cycle <i>Suggested start value: 10 ms</i>	
		Shake Amplitude Displays max. motor movement during phase finding <i>Used to optimize coarse tuning current and pulse duration.</i>	
	Phase Finding		Start Current Initial pulse amplitude for coarse tuning cycle <i>Suggested start value: 5 %</i>

Phase Finding	Control window (in alphabetic order)	Explanation <i>Input values</i>
		Final Current
		Final pulse amplitude for coarse tuning cycle
		<i>Suggested final value:</i> 10...100 %

Tab. 7.6: Control windows in "PHASE FINDING" tab

### 7.4.3.5 Control windows in "CAN" tab

Enter CAN bus baud rate and timing parameters.

CAN bus usage depends on custom specific firmware used.



The CAN interface will be implemented in a next version – no settings needed.

In case of errors or other service related questions contact MACCON tech support.

CAN	Control window (in alphabetic order)	Explanation <i>Input values</i>
		Bit timing prescaler Change prescaler for achieving correct baud rate. <i>see below "Bit timing T1, T2"</i>
		Bit timing T1 These parameters are used for CAN Baud rate setting. <i>Initial Values T1 = 4, change prescaler for achieving correct baud rate.</i>
		Bit timing T2 These parameters are used for CAN Baud rate setting. <i>Initial Values T2 = 5, change prescaler for achieving correct baud rate.</i>
		CAN baud rate Actual CAN baud rate as calculated from bit timing T1/T2 and prescaler. <i>Display only.</i>
CAN		CAN receive count CAN telegram counter for valid telegrams in receive direction.

CAN	Control window (in alphabetic order)	Explanation <i>Input values</i>
	<div style="border: 1px solid black; padding: 5px;"> <p>&lt;0&gt; CAN transmit count</p> <div style="display: flex; align-items: center; justify-content: center;"> <span style="writing-mode: vertical-rl; transform: rotate(180deg); font-size: small; margin-right: 5px;">CAN</span> <div style="border: 1px solid black; padding: 5px; text-align: center;"> <div style="display: flex; justify-content: space-around; width: 100px;"> <span>+</span><span>+</span><span>+</span><span>+</span><span>+</span><span>+</span><span>+</span><span>+</span><span>+</span><span>+</span> </div> <div style="display: flex; justify-content: center; align-items: center; gap: 5px;"> <span style="border: 1px solid black; padding: 2px 5px;">0</span> </div> </div> </div> </div>	<p>CAN Transmit count</p> <p>CAN telegram counter for valid telegrams in transmit direction.</p>
	<div style="border: 1px solid black; padding: 5px;"> <p>&lt;0&gt; CAN type</p> <div style="display: flex; align-items: center; justify-content: center;"> <span style="writing-mode: vertical-rl; transform: rotate(180deg); font-size: small; margin-right: 5px;">CAN</span> <div style="border: 1px solid black; padding: 5px; text-align: center;"> <div style="display: flex; justify-content: space-around; width: 100px;"> <span>+</span><span>+</span><span>+</span><span>+</span><span>+</span><span>+</span><span>+</span><span>+</span><span>+</span><span>+</span> </div> <div style="display: flex; justify-content: center; align-items: center; gap: 5px;"> <input checked="" type="radio"/> Standard (11 Bit)  <input type="radio"/> Extended (29 Bit)                 </div> </div> </div> </div>	<p>CAN type</p> <p>CAN identifier length must be set according to master setting.</p>
	<div style="border: 1px solid black; padding: 5px;"> <p>&lt;0&gt; CAN: Act. Position Scaling</p> <div style="display: flex; align-items: center; justify-content: center;"> <span style="writing-mode: vertical-rl; transform: rotate(180deg); font-size: small; margin-right: 5px;">CAN</span> <div style="border: 1px solid black; padding: 5px; text-align: center;"> <div style="display: flex; justify-content: space-around; width: 100px;"> <span>+</span><span>+</span><span>+</span><span>+</span><span>+</span><span>+</span><span>+</span><span>+</span><span>+</span><span>+</span> </div> <div style="display: flex; justify-content: center; align-items: center; gap: 5px;"> <span style="border: 1px solid black; padding: 2px 5px;">0</span> / 2<sup>n</sup> </div> </div> </div> </div>	<p>CAN: Act. Position Scaling</p>
	<div style="border: 1px solid black; padding: 5px;"> <p>&lt;0&gt; CAN: commanded value</p> <div style="display: flex; align-items: center; justify-content: center;"> <span style="writing-mode: vertical-rl; transform: rotate(180deg); font-size: small; margin-right: 5px;">CAN</span> <div style="border: 1px solid black; padding: 5px; text-align: center;"> <div style="display: flex; justify-content: space-around; width: 100px;"> <span>+</span><span>+</span><span>+</span><span>+</span><span>+</span><span>+</span><span>+</span><span>+</span><span>+</span><span>+</span> </div> <div style="display: flex; justify-content: center; align-items: center; gap: 5px;"> <span style="border: 1px solid black; padding: 2px 5px;">0</span> </div> </div> </div> </div>	<p>CAN: commanded value</p> <p>Display of commanded setpoint (referring to current or speed, mode dependent) for CAN operation.</p>
	<div style="border: 1px solid black; padding: 5px;"> <p>&lt;0&gt; CAN: commanded value 2</p> <div style="display: flex; align-items: center; justify-content: center;"> <span style="writing-mode: vertical-rl; transform: rotate(180deg); font-size: small; margin-right: 5px;">CAN</span> <div style="border: 1px solid black; padding: 5px; text-align: center;"> <div style="display: flex; justify-content: space-around; width: 100px;"> <span>+</span><span>+</span><span>+</span><span>+</span><span>+</span><span>+</span><span>+</span><span>+</span><span>+</span><span>+</span> </div> <div style="display: flex; justify-content: center; align-items: center; gap: 5px;"> <span style="border: 1px solid black; padding: 2px 5px;">0</span> </div> </div> </div> </div>	<p>CAN: commanded value 2</p> <p>Display of commanded setpoint (referring to current or speed, mode dependent) for CAN operation.</p>
	<div style="border: 1px solid black; padding: 5px;"> <p>&lt;0&gt; CAN: Max. Speed</p> <div style="display: flex; align-items: center; justify-content: center;"> <span style="writing-mode: vertical-rl; transform: rotate(180deg); font-size: small; margin-right: 5px;">CAN</span> <div style="border: 1px solid black; padding: 5px; text-align: center;"> <div style="display: flex; justify-content: space-around; width: 100px;"> <span>+</span><span>+</span><span>+</span><span>+</span><span>+</span><span>+</span><span>+</span><span>+</span><span>+</span><span>+</span> </div> <div style="display: flex; justify-content: center; align-items: center; gap: 5px;"> <span style="border: 1px solid black; padding: 2px 5px;">0</span> <span style="border: 1px solid black; padding: 2px 5px;">0</span> <span style="border: 1px solid black; padding: 2px 5px;">0</span> <span style="border: 1px solid black; padding: 2px 5px;">1</span> </div> </div> </div> </div>	<p>CAN: Max. Speed</p> <p>Maximum operating speed in CAN control mode.</p>
	<div style="border: 1px solid black; padding: 5px;"> <p>&lt;0&gt; Receive ID 1</p> <div style="display: flex; align-items: center; justify-content: center;"> <span style="writing-mode: vertical-rl; transform: rotate(180deg); font-size: small; margin-right: 5px;">CAN</span> <div style="border: 1px solid black; padding: 5px; text-align: center;"> <div style="display: flex; justify-content: space-around; width: 100px;"> <span>+</span><span>+</span><span>+</span><span>+</span><span>+</span><span>+</span><span>+</span><span>+</span><span>+</span><span>+</span> </div> <div style="display: flex; justify-content: center; align-items: center; gap: 5px;"> <span style="border: 1px solid black; padding: 2px 5px;">0</span> <span style="border: 1px solid black; padding: 2px 5px;">0</span> <span style="border: 1px solid black; padding: 2px 5px;">0</span> <span style="border: 1px solid black; padding: 2px 5px;">0</span> <span style="border: 1px solid black; padding: 2px 5px;">0</span> <span style="border: 1px solid black; padding: 2px 5px;">0</span> <span style="border: 1px solid black; padding: 2px 5px;">0</span> <span style="border: 1px solid black; padding: 2px 5px;">0</span> </div> </div> </div> </div>	<p>Receive ID 1</p> <p>CAN identifiers for transmit and receive telegrams have to be set corresponding to master controller.</p>
	<div style="border: 1px solid black; padding: 5px;"> <p>&lt;0&gt; Receive ID 2</p> <div style="display: flex; align-items: center; justify-content: center;"> <span style="writing-mode: vertical-rl; transform: rotate(180deg); font-size: small; margin-right: 5px;">CAN</span> <div style="border: 1px solid black; padding: 5px; text-align: center;"> <div style="display: flex; justify-content: space-around; width: 100px;"> <span>+</span><span>+</span><span>+</span><span>+</span><span>+</span><span>+</span><span>+</span><span>+</span><span>+</span><span>+</span> </div> <div style="display: flex; justify-content: center; align-items: center; gap: 5px;"> <span style="border: 1px solid black; padding: 2px 5px;">0</span> <span style="border: 1px solid black; padding: 2px 5px;">0</span> <span style="border: 1px solid black; padding: 2px 5px;">0</span> <span style="border: 1px solid black; padding: 2px 5px;">0</span> <span style="border: 1px solid black; padding: 2px 5px;">0</span> <span style="border: 1px solid black; padding: 2px 5px;">0</span> <span style="border: 1px solid black; padding: 2px 5px;">0</span> <span style="border: 1px solid black; padding: 2px 5px;">0</span> </div> </div> </div> </div>	<p>Receive ID 2</p> <p>CAN identifiers for transmit and receive telegrams have to be set corresponding to master controller.</p>
	<div style="border: 1px solid black; padding: 5px;"> <p>&lt;0&gt; Receive timeout</p> <div style="display: flex; align-items: center; justify-content: center;"> <span style="writing-mode: vertical-rl; transform: rotate(180deg); font-size: small; margin-right: 5px;">CAN</span> <div style="border: 1px solid black; padding: 5px; text-align: center;"> <div style="display: flex; justify-content: space-around; width: 100px;"> <span>+</span><span>+</span><span>+</span><span>+</span><span>+</span><span>+</span><span>+</span><span>+</span><span>+</span><span>+</span> </div> <div style="display: flex; justify-content: center; align-items: center; gap: 5px;"> <span style="border: 1px solid black; padding: 2px 5px;">0</span> ms                 </div> </div> </div> </div>	<p>Receive timeout</p> <p>This timeout can be used for a security shutdown of the drive if no CAN telegram is received.</p> <p><i>Set to zero to disable timeout detection.</i></p>

CAN	Control window (in alphabetic order)	Explanation <i>Input values</i>
		Transmit ID 1 CAN identifiers for transmit and receive telegrams have to be set corresponding to master controller.
		Transmit ID 2 CAN identifiers for transmit and receive telegrams have to be set corresponding to master controller.
		Transmit period Time between 2 transmit telegrams of ID1. The transmit periods for telegrams 2 (and 3) can be indirectly set by multipliers of this value.

Tab. 7.7: Control windows in CAN tab

#### 7.4.3.6 Control windows in “OFFSET” tab

The offsets of analogue inputs, phase currents and DC tach input can be calibrated here.

OFFSET	Control window (in alphabetic order)	Explanation <i>Input values</i>
		Analog Cmd Input 1 Actual value of analog inputs. <i>Standard: 0</i> <i>Range -32768 to +32767</i>
		Analog Cmd Input 2 Actual value of analog inputs <i>Standard: 0</i> <i>Range -32768 to +32767</i>
		Analog Cmd Input Aux Actual value of analog inputs <i>Standard: 0</i> <i>Range -32768 to +32767</i>
OFFSET		Analog-In Aux Offset Offset voltage for calibration of analog aux input <i>Standard: 0</i>

OFFSET	Control window (in alphabetic order)	Explanation <i>Input values</i>
OFFSET		Analog-In 1 Offset Offset voltage for calibration of analog input 1 <i>Standard: 0</i>
		Analog-In 2 Offset Offset voltage for calibration of analog input 2 <i>Standard: 0</i>
		DC Tach Input Actual value of DC Tach input <i>Range -32768 to +32767</i>
		DC Tach Offset Offset for calibrating DC Tach input <i>Adjust to get a zero reading on parameter "DC Tach Input" at standstill</i>
OFFSET		Phase Curr. Offset U Offset for calibrating current sensor of motor phase U <i>Set by auto compensation algorithm while drive is disabled</i>
		Phase Curr. Offset V Offset for calibrating current sensor of motor phase V <i>Set by auto compensation algorithm while drive is disabled</i>
		Phase Current U Actual value of current sensor of phase U <i>Range -32768 to +32767</i>
OFFSET		Phase Current V Actual value of current sensor of phase V <i>Range -32768 to +32767</i>

Tab. 7.8: Control windows in OFFSET tab









**7.4.3.7 Control windows in "MOTION SENSOR MONITORING" tab**

Different internal signals of certain feedback systems can be watched here.

For sinusoidal encoders, an automatic offset compensation routine is available. The compensation values can be adjusted manually.










EnDat sensors are initialized automatically.

<b>MOTION SENSOR MONITORING</b>	<b>Control window (in alphabetic order)</b>	<b>Explanation <i>Input values</i></b>
		Dig. Encoder State Display only
		EnDat Multi Turns Multi-turns of connected EnDat position sensor. <i>Data are read out from connected EnDat device.</i>
		EnDat Sensor Type  <i>Data are read out from connected EnDat device.</i>
		EnDat Sine Cycles/Turn or /m Monitoring and debugging parameters derived from the EnDat signal. <i>Data are read out from connected EnDat device.</i>
		EnDat Steps/Turn or Steps/m Resolution of connected EnDat position sensor.
<p><b>MOTION SENSOR MONITORING</b></p>		Sensor Initialization State of running or finished digital sensor initialization (EnDat/Hiperface/BiSS). <i>Display only.</i>





MOTION SENSOR MONITORING

MOTION SENSOR MONITORING

Control window (in alphabetic order)	Explanation <i>Input values</i>
	<p>Sine Enc.2 / Resolver offset comp. (cos)</p> <p>Offset compensation value for cosine channel of sine encoder 2 (or resolver).</p> <p><i>Set by auto compensation algorithm, can also be adjusted manually.</i></p>
	<p>Sine Enc.2 / Resolver offset comp. (sin)</p> <p>Offset compensation value for sine channel of sine encoder 2 (or resolver).</p> <p><i>Set by auto compensation algorithm, can also be adjusted manually.</i></p>
	<p>Sine Enc.2 / Resolver offset comp.</p> <p>State / result of automatic offset compensation of analog inputs of sine encoder 2 (or resolver).</p>
	<p>Sine Enc.2 / Resolver offset comp. (Start)</p> <p>Check to start automatic offset calibration of analog inputs of sine encoder 2 (also used for resolver)</p>
	<p>Sine encoder 1 offset comp.</p> <p>State/result of automatic offset compensation of analog inputs of sine encoder 1</p>
	<p>Sine encoder 1 offset comp. (cos)</p> <p>Offset compensation value for cosine channel of sine encoder 1</p> <p><i>Set by auto compensation algorithm. Can also be adjusted manually.</i></p>
	<p>Sine encoder 1 offset comp. (sin)</p> <p>Offset compensation value for sine channel of sine encoder 1</p> <p><i>Set by auto compensation algorithm. Can also be adjusted manually.</i></p>

MOTION SENSOR MONITORING	Control window (in alphabetic order)	Explanation <i>Input values</i>
		Sine encoder 1 offset comp. (Start)
		SinEnc1 Amplitude Actual data for checking operation of sin/cos encoder
		SinEnc1 Max. Voltage A Stored min./max. values for debugging encoder problems.
MOTION SENSOR MONITORING		SinEnc1 Max. Voltage B Positive peak voltage of cosine signal of sine encoder 1.
		SinEnc1 Min. Volt. A Stored min./max. values for debugging encoder problems.
		SinEnc1 Min. Volt. B Negative peak voltage of cosine signal of sine encoder 1.
		SinEnc1 Offset A Offset compensation value for sine channel of sine encoder 1. <i>Set by software. Use "Sine encoder 1 offset comp. (sin)" to manually adjust offset.</i>
		SinEnc1 Offset B Offset compensation value for cosine channel of sine encoder 1. <i>Set by software. Use "Sine encoder 1 offset comp. (cos)" to manually adjust offset.</i>
MOTION SENSOR MONITORING		SinEnc1 Phase Actual electrical angle of sine encoder 1 sin/cos signals. <i>Range 0..65535 = 0..360 deg (el)</i>

MOTION SENSOR MONITORING	Control window (in alphabetic order)	Explanation <i>Input values</i>
		<p>SinEnc1 Voltage A</p> <p>Analog voltage of sine channel of sine encoder 1</p> <p><i>Range -32768 to +32767</i></p>
		<p>SinEnc1 Voltage B</p> <p>Analog voltage of sine channel of cosine encoder 1</p> <p><i>Range -32768 to +32767</i></p>
		<p>SinEnc2 Min. Volt A</p> <p>Negative peak voltage of sine signal of sine encoder 2 (or resolver).</p> <p><i>Range -32768 to +32767</i></p>
		<p>SinEnc2 Amplitude</p> <p>Amplitude of sine encoder 2 or resolver</p> <p><i>Used by MACCON tech support.</i></p>
MOTION SENSOR MONITORING		<p>SinEnc2 Max. Volt. B</p> <p>Positive peak voltage of cosine signal of sine encoder 2 (or resolver).</p> <p><i>Range -32768 to +32767</i></p>
		<p>SinEnc2 Voltage A</p> <p>Analog voltage of sine channel of sine encoder 2 (or resolver).</p> <p><i>Range -32768 to +32767</i></p>
		<p>SinEnc2 Min. Volt. B</p> <p>Negative peak voltage of cosine signal of sine encoder 2 (or resolver).</p> <p><i>Range -32768 to +32767</i></p>
MOTION SENSOR MONITORING		<p>SinEnc2 Offset A</p> <p>Offset compensation value for sine channel of sine encoder 2 (or resolver).</p> <p>Set by software. <i>Use "Sine encoder 2 /Resolver offset comp. (sin)" to manually adjust offset.</i></p>

MOTION SENSOR MONITORING	Control window (in alphabetic order)	Explanation <i>Input values</i>
	<div style="border: 1px solid black; padding: 5px;"> <p>&lt;1&gt; SinEnc2 Offset B</p>  </div>	<p>SinEnc2 Offset B</p> <p>Offset compensation value for sine channel of cosine encoder 2 (or resolver).</p> <p>Set by software. <i>Use "Sine encoder 2 /Resolver offset comp. (sin)" to manually adjust offset.</i></p>
	<div style="border: 1px solid black; padding: 5px;"> <p>&lt;1&gt; SinEnc2 Phase</p>  </div>	<p>SinEnc2 Phase</p> <p>Actual electrical angle of sine encoder 1 sin/cos signals</p> <p><i>Range 0..65535 = 0..360 deg (el)</i></p>
	<div style="border: 1px solid black; padding: 5px;"> <p>&lt;1&gt; SinEnc2 Max.Volt. A</p>  </div>	<p>SinEnc2 Max. Volt. A</p> <p>Positive peak voltage of sine signal of sine encoder 2 (or resolver)</p> <p><i>Range -32768 to +32767</i></p>
MOTION SENSOR MONITORING	<div style="border: 1px solid black; padding: 5px;"> <p>&lt;1&gt; SinEnc2 Voltage B</p>  </div>	<p>SinEnc2 Voltage B</p> <p>Analog voltage of sine channel of sine encoder 2 (or resolver)</p> <p><i>Range -32768 to +32767</i></p>

Tab. 7.9: Control windows in "MOTION SENSOR MONITORING" tab

**7.4.3.8 Control windows in "SPEED / CURRENT CONTROL" tab**

In this section the control parameters for current and speed loop are adjusted.





The current and speed loops can be optimized by monitoring the step response of the system, e.g. by applying a square wave voltage as current or speed command.

It is necessary to match the servo controller to the mechanics of the drive system in order to optimize performance in the velocity control mode.

SPEED / CURRENT CONTROL	Control window (in alphabetic order)	Explanation <i>Input values</i>
	<div style="border: 1px solid black; padding: 5px;"> <p>&lt;0&gt; Commutation Sensor Select</p> <ul style="list-style-type: none"> <li><input type="radio"/> &lt;not used&gt;</li> <li><input type="radio"/> SineEnc&lt;1&gt;</li> <li><input type="radio"/> SineEnc&lt;2&gt;</li> <li><input type="radio"/> Resolver</li> <li><input checked="" type="radio"/> TTL-Enc</li> <li><input type="radio"/> Hall</li> <li><input type="radio"/> SineEnc 3Ph</li> <li><input type="radio"/> EnDat SinCos</li> <li><input type="radio"/> EnDat Digital</li> <li><input type="radio"/> Hiperface</li> <li><input type="radio"/> Biss</li> <li><input type="radio"/> Netzer</li> <li><input type="radio"/> SSI</li> </ul> </div>	<p>Commutation Sensor Select</p> <p>Defines the feedback system which is used for phase and current control.</p> <p><i>It may be the same as speed and position sensor.</i></p>

SPEED / CURRENT CONTROL	Control window (in alphabetic order)	Explanation <i>Input values</i>
		Current Command D Display of actual current loop command (D vector)
		Current Command Q Display of actual current loop command (Q vector) <i>see in OPERATION chap.7.4.3.3</i>
		Current Control <i>see in OPERATION chap. 7.3.1.1</i>
		Current Control: D gain Parameter identification by optimization of current step response. <i>Set D gain only, if fast load changes are expected, see chap. 7.3.1.1 on page 71.</i>
		Current Control: I gain Parameter identification by optimization of current step response. <i>See chap. 7.3.1.1 on page 71.</i>
SPEED / CURRENT CONTROL		Current Control: P gain Parameter identification by optimization of current step response. <i>see chap. 7.3.1.1 on page 71.</i>
		Direction Direction setting for commutation sensor, depending on motor phase sensor orientation. <i>Standard: not inverted</i>
		I*t Current Limit I*t monitoring limit for creating a warning / error
SPEED / CURRENT CONTROL		I*t Limited Current Time I*t monitoring limit for creating a warning / error




**SPEED / CURRENT CONTROL**

Control window (in alphabetic order)	Explanation <i>Input values</i>
<p>&lt;2&gt; I*t Max. Current Time</p> 	<p>I*t Max. Current Time</p> <p>I*t monitoring limit for creating a warning / error</p>
<p>&lt;2&gt; Max. Current</p> 	<p>Max. Current</p> <p>Provides a current limit for all operating modes based on the maximum current of the drive.</p> <p><i>Reduce this value to a level according to your motor data.</i></p>
<p>&lt;2&gt; Motor Startup Synchronization</p> <p><input checked="" type="radio"/> On first Enabling only <input type="radio"/> On each Enabling</p>	<p>Motor Startup Synchronization</p> <p>After first enabling, the phase finding result can be used until power-off. The phase finding can anyway be performed on each enabling.</p>
<p>&lt;2&gt; Motor Startup Synchronization</p> <p><input checked="" type="radio"/> none (for absolute sensors) <input type="radio"/> Phase Finding <input type="radio"/> Phase Finding + Encoder Index <input type="radio"/> Hall Sensors <input type="radio"/> Hall + Encoder Index</p>	<p>Motor Startup Synchronization</p> <p><i>Choose "Phase Finding" when – no hall sensors and – no analog encoder are present.</i></p>
<p>&lt;1&gt; Phase Curr. P Gain (fast)</p> 	<p>Phase Curr. P Gain (fast)</p> <p>Fast phase current controller, used in parallel to the slower field-oriented controller, to increase loop bandwidth.</p>
<p>&lt;0&gt; Position Sensor Select</p> <p><input type="radio"/> &lt;not used&gt; <input type="radio"/> SineEnc&lt;1&gt; <input type="radio"/> SineEnc&lt;2&gt; <input type="radio"/> Resolver <input checked="" type="radio"/> TTL-Enc <input type="radio"/> - <input type="radio"/> SineEnc 3Ph <input type="radio"/> EnDat SinCos <input type="radio"/> EnDat Digital <input type="radio"/> Hiperface <input type="radio"/> Biss <input type="radio"/> Netzer <input type="radio"/> SSI</p>	<p>Position Sensor Select</p> <p>Defines the feedback system which is used for position control loop.</p> <p><i>Select acc. present sensor type.</i></p>
<p>&lt;2&gt; Rotatory Speed</p> 	<p>Rotatory Speed</p> <p>Rotatory motor: Speed as derived from active speed sensor</p>
	Speed Clipping

**SPEED / CURRENT CONTROL**

SPEED / CURRENT CONTROL	Control window (in alphabetic order)	Explanation <i>Input values</i>
		Displays current reduction caused by overspeed protection. See parameter "Speed Limit"
		Speed Control: Actual Speed Actual speed as derived from active speed sensor position.
		Speed Control: D gain Set D gain only if fast load changes are expected. <i>see chap. 7.3.1.1 on page 71.</i>
		Speed Control: I gain Set I gain only if fast load changes are expected. <i>see chap. 7.3.1.1 on page 71.</i>
		Speed Control: KVFR Speed control feed forward for faster reaction of current controller. <i>see chap. 7.4.3.8 on page 93</i>
		Speed Control: P gain P gain of speed control loop. <i>see chap. 7.3.1.1 on page 71.</i>
SPEED / CURRENT CONTROL		Speed Limit Speed limit in current control mode.
		Speed Ramp Check to enable slope control of internal speed command. <i>see parameters</i> – "Speed: Max. Acceleration" and – "Speed: Max. Deceleration".
		Speed Sensor Select Defines the feedback system which is used for speed control loop. <i>Selection acc. present sensor type.</i>
		Speed: Max. Acceleration Specify the acceleration limit for speed control mode. (If enabled; see parameter "Speed: Ramp"). Reduce the slope of the speed command if necessary.
		Speed: Max. Deceleration






SPEED / CURRENT CONTROL	Control window (in alphabetic order)	Explanation <i>Input values</i>
		Specify the deceleration limit for speed control mode. (If enabled; see parameter "Speed: Ramp"). Reduces the slope of the speed command if necessary
		Tach Lowpass, MAF For resolver operation. <i>The lowpass has to be configured according to the following table, see chap. 7.3.2.5</i>
SPEED / CURRENT CONTROL		Tach Lowpass, PT1 PT1 filter for smoothing the speed loop reaction. PT1 lowpass filter for smoothing the actual speed feedback signal, see chap. 7.3.2.6 <i>Higher numbers result in lower bandwidth; each increment reduces the bandwidth by 0.7</i>










Tab. 7.10: Control windows in "SPEED / CURRENT CONTROL" tab











### 7.4.3.9 Control windows in "MOTION SENSORS" tab

Enter all relevant data for your applicable feedback sensors.

MOTION SENSORS	Control window (in alphabetic order)	Explanation <i>Input values</i>
		DC Tach Full Scale Speed Speed at maximum DC tach input voltage.
		DC Tach Input Actual value of DC Tach input. <i>Range -32768 to +32767</i>
		DC Tach Offset Offset for calibrating DC Tach input. <i>Adjust to get a zero reading on parameter "DC Tach Input" at standstill.</i>
		Sine Enc. 1 Cycles/Rev

MOTION SENSORS	Control window (in alphabetic order)	Explanation <i>Input values</i>
MOTION SENSORS		Resolution of Sine Encoder 1 (sine cycles per revolution or sine cycles per meter for linear sensors).  <i>Set acc. to used sine encoder.</i>
		EXE: Burst Freq.  Parameter for emulation of an incremental encoder, which may be used to drive an external position controller.
		EXE: Divider  Scaling factor for encoder output, depends on position sensor resolution.
		EXE: Divider  Scaling factor for encoder output, depends on position sensor resolution.  <i>The emulated incremental encoder has a resolution of the sensor used for commutation (as shown in the parameter "COMM_SENS: Increments /Rev or /m") divided by this factor.</i>
MOTION SENSORS		Hall Observer I Gain  Gain of the hall position observer loop.
		Hall Observer P Gain  P gain of the hall position observer loop.
		Hall Phases  Hall sensor configuration:  3 Phases: Using 3 hall sensors with 120 degree spacing 2 Phases: Using 3 hall sensors with 120 degree spacing 12 Steps: for special use only
		Hall sensor type  Supply voltage of connected hall sensor.







MOTION SENSORS	Control window (in alphabetic order)	Explanation <i>Input values</i>
		<p>HALL State</p> <p>Signal state and rotating direction of the hall sensors.</p> <p><i>Display only</i></p>
		<p>Incr. Enc.: Lines/Rev or /m</p> <p>Set up the encoder lines per revolution.</p> <p>1...999999999</p>
MOTION SENSORS		<p>Incremental Encoder Type</p> <p>Electrical interface of connected encoder</p>
		<p>MaxHallTimeMS</p> <p>Hall pulse duration for switching between hex step and sine commutation</p>
		<p>Netzer Coarse Cycles</p> <p>Coarse track cycles of attached Netzer sensor</p>
MOTION SENSORS		<p>Netzer Coarse offset compensation (cos)</p> <p>Offset voltage of coarse track (cos); Result of auto offset compensation, can be adjusted manually.</p> <p><i>Used by MACCON tech support.</i></p>
		<p>Netzer Coarse offset compensation (sin)</p> <p>Offset voltage of coarse track (sin); Result of auto offset compensation, can be adjusted manually.</p> <p><i>Used by MACCON tech support.</i></p>
		<p>Netzer Coarse/Fine Shift</p> <p>Phase shift between coarse and fine track. Result of auto offset compensation, can be adjusted manually.</p> <p><i>Used by MACCON tech support.</i></p>
		<p>Netzer Sensor Calibration</p> <p>Controls automatic Netzer sensor calibration.</p> <p><i>Used by MACCON tech support.</i></p> <p>Pga Gains</p>

MOTION SENSORS	Control window (in alphabetic order)	Explanation <i>Input values</i>
		Gain settings for DC tach input and phase voltage measurement  <i>Used by MACCON tech support.</i>
MOTION SENSORS		Resolver Frequency  Phase shift compensation for resolver  <i>Refer to Tab. 7.1.</i>
		Resolver Gain  Setup acc. to motor/resolver data sheet.
		Resolver Phase  Setup acc. to motor/resolver data sheet.
		Resolver Pole Pairs  <i>Pole pairs of resolver</i>  Setup acc. to motor/resolver data sheet.
		Sine Enc. 1 Cycles/Rev or /m  Set up the resolution in full sinusoidal cycles per revolution.
MOTION SENSORS		Sine Enc. 2 Cycles/Rev or /m  Set up the resolution in full sinusoidal cycles per revolution.
		Sine Enc2 Amplitude  <i>Amplitude of sine encoder 2 or resolver</i>  <i>Used by MACCON tech support.</i>
		Use DC Tach  Speed signal is created from DC Tach.  <i>Display only.</i>
		Use Hall  Speed signal is created from hall sensors  <i>Display only.</i>

Tab. 7.11: Control windows in "MOTION SENSORS" tab

7.4.3.10 Control windows in "SYSTEM SETUP" tab

This chapter specifies the basic description for the used motor type.

SYSTEM SETUP	Control window (in alphabetic order)	Explanation <i>Input values</i>
		<p>Back EMF Const</p> <p>EMF constant of single phase circuit.</p> <p><i>The EMF value measured between two motor phases (RMS) has to be divided by <math>\sqrt{3}</math></i></p> <p><i>Enter the value according to your motor data sheet.</i></p>
		<p>Motor Inductance (D)</p> <p>D component of motor inductance of single phase equivalent circuit.</p> <p>Enter the value according to your motor data sheet. The inductance measured between two motor phases has to be divided by 2.</p> <p><i>This parameter is split into Motor Inductance "Q" and "D" to improve field weakening capabilities.</i></p>
		<p>Motor Inductance (Q)</p> <p>D component of motor inductance of single phase equivalent circuit.</p> <p>Enter the value according to your motor data sheet. The inductance measured between two motor phases has to be divided by 2.</p> <p><i>see above – Motor Inductance (D)</i></p>
		<p>Motor temp sensor type</p> <p>A fault message and controller turn-off result at 130° C when either one of these sensors was selected.</p> <p><i>Select the sensor type used.</i></p>
SYSTEM SETUP		<p>Motor Type</p> <p>Select the motor type.</p> <p>Rotary or Linear</p>
		<p>Motor Winding</p> <p>Choice between</p> <ul style="list-style-type: none"> <li>- 3 phase brushless</li> <li>- 2 phase brushless or</li> </ul>


SYSTEM SETUP	Control window (in alphabetic order)	Explanation <i>Input values</i>
		– DC motor (with brushes). <i>Select the motor type.</i>
		Pole Pairs Enter the value according to your motor data sheet. <i>Only for <b>rotary</b> motors.</i>
		Pole Pitch <b>Motor Type = Linear</b> Enter the value according to your motor data sheet. <i>Only for <b>linear</b> motors.</i>
SYSTEM SETUP		PWM Frequency Sets the PWM frequency of the power stage.
		PWM Frequency (FPGA) Displays the PWM frequency of the power stage. <i>For MACCON tech assistance only.</i>

Tab. 7.12: Control windows in "SYSTEM SETUP" tab

7.4.3.11 Control windows in "SWM STATUS" tab

Firmware versions and internal status flags are displayed here. This information may be needed if queried by MACCON tech support.

<b>SWM STATUS</b>	<b>Control window</b> (in alphabetic order)	<b>Explanation</b> <i>Input values</i>
<b>SWM STATUS</b>	<div style="border: 1px solid black; padding: 5px;"> <p>&lt;2&gt; DSP CPU load</p> <p style="font-size: small; color: purple;">DEBUG</p> <p style="text-align: center; font-size: large;">72.7%</p> </div>	<p>DSP CPU load</p> <p>Display percentage DSP processing time.</p> <p><i>For MACCON tech assistance only.</i></p>
	<div style="border: 1px solid black; padding: 5px;"> <p>&lt;2&gt; DSP Error Flags (live)</p> <ul style="list-style-type: none"> <li><input type="radio"/> OverCurrent</li> <li><input type="radio"/> I2t-Warning</li> <li><input type="radio"/> I2t-Error</li> <li><input type="radio"/> OverVoltage</li> <li><input type="radio"/> .</li> <li><input type="radio"/> .</li> <li><input type="radio"/> .</li> <li><input type="radio"/> .</li> <li><input type="radio"/> OverCurrent HW</li> <li><input type="radio"/> OverCurrent2 HW</li> <li><input type="radio"/> UnderVolt int.</li> </ul> <p style="font-size: small; color: purple;">INTERNAL</p> </div>	<p>DSP Error Flags (live)</p> <p>Displays the DSP error flags.</p> <p><i>For MACCON tech assistance only.</i></p>
	<div style="border: 1px solid black; padding: 5px;"> <p>&lt;2&gt; DSP SW Version</p> <p style="font-size: small; color: purple;">DEBUG</p> <p style="text-align: center; font-size: large;">1406A HEX</p> </div>	<p>DSP SW Version</p> <p>Display of the SW version of DSP.</p> <p><i>For MACCON tech assistance only.</i></p>
	<div style="border: 1px solid black; padding: 5px;"> <p>&lt;1&gt; FPGA Status Flags 2</p> <p style="font-size: small; color: purple;">INTERNAL</p> <ul style="list-style-type: none"> <li><input type="radio"/> Brake On</li> </ul> </div>	<p>FPGA Status Flags 2</p> <p>Displays state of brake.</p> <p><i>For MACCON tech assistance only.</i></p>
	<div style="border: 1px solid black; padding: 5px;"> <p>&lt;1&gt; FPGA Status Flags</p> <ul style="list-style-type: none"> <li><input type="radio"/> Enabled</li> <li><input type="radio"/> EnabDspUser</li> <li><input type="radio"/> EnabStrUser</li> <li><input checked="" type="radio"/> EnabSwitch</li> <li><input checked="" type="radio"/> DspEnabSW</li> <li><input checked="" type="radio"/> StrEnabSW</li> <li><input type="radio"/> DspSWErr</li> <li><input type="radio"/> StrSWErr</li> <li><input type="radio"/> OCurr1</li> <li><input type="radio"/> OCurr2</li> <li><input type="radio"/> UndVolt</li> <li><input type="radio"/> DSP Timeout</li> <li><input type="radio"/> STR Timeout</li> </ul> <p style="font-size: small; color: purple;">INTERNAL</p> </div>	<p>Status Flags</p> <p>Displays internal enable and error flags.</p> <p><i>For MACCON tech assistance only.</i></p>
	<div style="border: 1px solid black; padding: 5px;"> <p>&lt;1&gt; FPGA Version</p> <p style="font-size: small; color: purple;">DEBUG</p> <p style="text-align: center; font-size: large;">14060223 HEX</p> </div>	<p>FPGA Version</p> <p>Display of FPGA code version.</p> <p><i>For MACCON tech assistance only.</i></p>
	<div style="border: 1px solid black; padding: 5px;"> <p>&lt;0&gt; STR Error Flags (live)</p> <ul style="list-style-type: none"> <li><input type="radio"/> OverTemp.Drive</li> <li><input type="radio"/> OverTemp.Motor</li> <li><input type="radio"/> EndatError</li> <li><input type="radio"/> CanTimeout</li> <li><input type="radio"/> CanMsgError</li> <li><input type="radio"/> Custom Err.1</li> <li><input type="radio"/> Custom Err.2</li> </ul> <p style="font-size: small; color: purple;">INTERNAL</p> </div>	<p>STR Error Flags (live)</p> <p>Displays the µC flags.</p> <p><i>For MACCON tech assistance only.</i></p>

SWM STATUS	Control window (in alphabetic order)	Explanation <i>Input values</i>
SWM STATUS		STR710 CPU load Display percentage of $\mu$ C time utilization. <i>For MACCON tech assistance only.</i>

**Tab. 7.13:** Control windows in "SWM STATUS" tab





7.4.3.12 Control windows in "DATA ACQUISITION" tab

Different internal data, mainly concerning the power stage and processor status, is summarized in this chapter.

Limitations for power stage bus voltage and current can be set. The state of digital I/O as well as processor status flags can be monitored.

You can select the assignment of signals to analog outputs. SWM7 software offers six analogue outputs which can be widely configured to the specific application needs.

DATA ACQUISITION

Control window (in alphabetic order)	Explanation <i>Input values</i>
<p>&lt;2&gt; ANAOUT1 Gain</p> 	<p>ANAOUT1 Gain</p> <p>Use the gain setting for scaling the linked signal to the output range.</p> <p><i>Gain 1.0 outputs</i></p> <ul style="list-style-type: none"> <li>- -10 V...+10 V or</li> <li>- 0...+5 V *</li> </ul> <p>for signal values of -1.0 ... +1.0 (* Depends on parameter "ANAOUT1 Voltage Range".</p>
<p>&lt;2&gt; ANAOUT1 Offset</p> 	<p>ANAOUT1 Offset</p> <p>Is used for calibrating the level voltage of the output.</p>
<p>&lt;2&gt; ANAOUT1 Select</p> <ul style="list-style-type: none"> <li><input type="radio"/> IActU</li> <li><input type="radio"/> IActV</li> <li><input type="radio"/> IActQ</li> <li><input type="radio"/> IActD</li> <li><input type="radio"/> CtrIOutQ</li> <li><input type="radio"/> CtrOutD</li> <li><input type="radio"/> PWM Cmd U</li> <li><input type="radio"/> PWM Cmd V</li> <li><input type="radio"/> PWM Cmd W</li> <li><input type="radio"/> Comm.Angle</li> <li><input type="radio"/> Act.Speed</li> <li><input type="radio"/> Speed.Cmd.</li> <li><input type="radio"/> Act.Curr</li> <li><input type="radio"/> Curr.Cmd.</li> <li><input type="radio"/> AnaCmd1</li> <li><input checked="" type="radio"/> AnaCmd2</li> <li><input type="radio"/> AnaCmdAux</li> <li><input type="radio"/> DcTach</li> <li><input type="radio"/> AUX1</li> <li><input type="radio"/> AUX2</li> <li><input type="radio"/> AUX3</li> <li><input type="radio"/> AUX4</li> <li><input type="radio"/> AUX5</li> <li><input type="radio"/> AUX6</li> <li><input type="radio"/> AUX7</li> <li><input type="radio"/> AUX8</li> <li><input type="radio"/> AUX9</li> <li><input type="radio"/> Debug1</li> <li><input type="radio"/> Debug2</li> <li><input type="radio"/> Debug3</li> </ul> <p>SWM7 : ANAOUT1...ANAOUT3 SWM7S: ANAOUT1...ANAOUT6</p>	<p>ANAOUT1 Select</p> <p>Select the signal for assignment to the certain output.</p> <p><i>Select the output for</i></p> <p><u>SWM7:</u> - ANAOUT1 to ANAOUT3</p> <p><u>SWM7S:</u> - ANAOUT1 to ANAOUT6</p>

DATA ACQUISITION

DATA ACQUISITION

Control window (in alphabetic order)	Explanation <i>Input values</i>
	<p>ANAOUT1-2 Voltage Range</p> <p>Select 5 V or +/-10 V range for each group of outputs.</p>
	<p>ANAOUT2 Gain</p> <p>Use the gain setting for scaling the linked signal to the output range.</p> <p><i>see "ANAOUT1 Gain"</i></p>
	<p>ANAOUT2 Offset</p> <p>Is used for calibrating the offset voltage of the output.</p>
	<p>ANAOUT3 Gain</p> <p>Use the gain setting for scaling the linked signal to the output range.</p> <p><i>see "ANAOUT1 Gain"</i></p>
	<p>ANAOUT3 Offset</p> <p>Is used for calibrating the offset voltage of the output.</p>
	<p>ANAOUT3-6 Voltage Range</p> <p>Select 5 V or +/-10 V range for each group of outputs.</p>

DATA ACQUISITION

DATA ACQUISITION

Control window (in alphabetic order)	Explanation <i>Input values</i>
<p>&lt;2&gt; AUX1 Select</p> <ul style="list-style-type: none"> <li><input checked="" type="radio"/> Bus Volt.</li> <li><input type="radio"/> Bus Curr.</li> <li><input type="radio"/> -</li> <li><input type="radio"/> -</li> <li><input type="radio"/> -</li> <li><input type="radio"/> UcmdQ</li> <li><input type="radio"/> UcmdD</li> <li><input type="radio"/> UcmdAng</li> <li><input type="radio"/> -</li> <li><input type="radio"/> S/L UcmdAngMod</li> <li><input type="radio"/> S/L AngleError</li> <li><input type="radio"/> S/L PhaseCorr.</li> <li><input type="radio"/> S/L Freq.Corr.</li> <li><input type="radio"/> S/L Ampl.Corr.</li> <li><input type="radio"/> EnvU</li> <li><input type="radio"/> EnvV</li> <li><input type="radio"/> DesCU</li> <li><input type="radio"/> DesCV</li> <li><input type="radio"/> CcmdQ</li> <li><input type="radio"/> CcmdD</li> <li><input type="radio"/> C/C Ud_Q</li> <li><input type="radio"/> C/C Ud_D</li> <li><input type="radio"/> -</li> <li><input type="radio"/> IActAngle</li> <li><input type="radio"/> PwmRb_U</li> <li><input type="radio"/> PwmRb_V</li> <li><input type="radio"/> PwmRb_W</li> </ul> <p style="color: purple; font-size: small;">DEBUG</p>	<p>AUX1 Select</p> <p>Select the signal for assignment to AUX1, which can be chosen by "ANAOUT x Select".</p> <p><i>For MACCON tech assistance only.</i></p>
<p>&lt;2&gt; Bus Current</p> <div style="border: 1px solid black; padding: 5px; width: fit-content;"> <p style="color: purple; font-size: x-small; margin: 0;">DATA_ACO</p> <p style="margin: 0;">■■■■ 0.0 A</p> </div>	<p>Bus Current</p> <p>Actual DC bus current. If wrong readings occur, ADC range setting may be wrong.</p> <p><i>Contact MACCON tech support before any adjustments!</i></p>
<p>&lt;2&gt; Bus Current ADC Range</p> <div style="border: 1px solid black; padding: 5px; width: fit-content;"> <p style="color: purple; font-size: x-small; margin: 0;">SYS</p> <p style="margin: 0;">+ + + + ■■ 9 0 A - - - -</p> </div>	<p>Bus Current ADC Range</p> <p>Sets the scaling for ADC converter. This value is constant for each device and must <b>not be changed</b> by the user.</p> <p><i>Change only when asked by MACCON tech support.</i></p>
<p>&lt;2&gt; Bus Current Limit</p> <div style="border: 1px solid black; padding: 5px; width: fit-content;"> <p style="color: purple; font-size: x-small; margin: 0;">SYS</p> <p style="margin: 0;">+ + + + ■■ 0.0 A (0=OFF) - - - -</p> </div>	<p>Bus Current Limit</p> <p>Limitation for DC bus current. If exceeded, the motor current will be reduced accordingly.</p>
<p>&lt;2&gt; Bus Current Offset</p> <div style="border: 1px solid black; padding: 5px; width: fit-content;"> <p style="color: purple; font-size: x-small; margin: 0;">SYS</p> <p style="margin: 0;">+ + + + + 0.0 A - - - -</p> </div>	<p>Bus Current Offset</p> <p>Sets the calibrating offset for ADC converter. Adjust to get zero reading while drive is disabled.</p> <p><i>Change only when asked by MACCON tech support.</i></p>

DATA ACQUISITION

**DATA ACQUISITION**

Control window (in alphabetic order)	Explanation <i>Input values</i>
	<p>Bus Voltage</p> <p>Actual DC bus voltage. If wrong readings occur, ADC range setting may be wrong.</p> <p><i>Contact MACCON tech support before any adjustments!</i></p>
	<p>Bus Voltage ADC Range</p> <p>Sets the scaling for AD converter. This value is constant for each device and must not be changed by the user.</p> <p><i>Change only when asked by MACCON tech support.</i></p>
<p><i>This value is constant for each device and must not be changed by the user.</i></p>	<p>Current ADC Range (peak)</p> <p>Motor current ADC range, sets the scaling for AD converter.</p> <p><i>Change only when asked by MACCON tech support.</i></p>
	<p>Digital In</p> <p>Status display of digital inputs.</p> <p><i>For customer specific applications only.</i></p>
	<p>Digital Out (DSP)</p> <p>Status display of digital outputs as commanded by DSP.</p> <p><i>For MACCON tech assistance only.</i></p>
	<p>Drive Temperature</p> <p>Actual drive temperature on °C.</p> <p>[°F]= 1.8 x [°C] + 32</p>

**DATA ACQUISITION**

DATA ACQUISITION	Control window (in alphabetic order)	Explanation <i>Input values</i>												
		DSP Error Flags (latched) Displays DSP error flags (latched). <i>For MACCON tech assistance only.</i>												
	<div style="border: 1px solid black; padding: 5px;"> <p>&lt;1&gt; FPGA Status Flags</p> <ul style="list-style-type: none"> <li><input type="radio"/> Enabled</li> <li><input type="radio"/> EnabDspUser</li> <li><input type="radio"/> EnabStrUser</li> <li><input checked="" type="radio"/> EnabSwitch</li> <li><input checked="" type="radio"/> DspEnabSW</li> <li><input checked="" type="radio"/> StrEnabSW</li> <li><input type="radio"/> DspSWErr</li> <li><input type="radio"/> StrSWErr</li> <li><input type="radio"/> OCurr1</li> <li><input type="radio"/> OCurr2</li> <li><input type="radio"/> UndVolt</li> <li><input type="radio"/> DSP Timeout</li> <li><input type="radio"/> STR Timeout</li> </ul> <p style="font-size: small; color: purple;">INTERNAL</p> </div>	FPGA Status Flags Displays internal enable and error flags. <i>For MACCON tech assistance only.</i>												
DATA ACQUISITION	<div style="border: 1px solid black; padding: 5px;"> <p>&lt;1&gt; FPGA Status Flags 2</p> <ul style="list-style-type: none"> <li><input type="radio"/> Brake On</li> </ul> <p style="font-size: small; color: purple;">INTERNAL</p> </div>	FPGA Status Flags 2 Displays state of brake. <i>For MACCON tech assistance only.</i>												
	<div style="border: 1px solid black; padding: 5px;"> <p>&lt;2&gt; Max. Bus Voltage</p> <div style="display: flex; align-items: center;"> <div style="font-size: small; color: purple; margin-right: 5px;">SYS</div> <div style="border: 1px solid black; padding: 2px;"> <table style="border-collapse: collapse; text-align: center;"> <tr><td>+</td><td>+</td><td>+</td><td>+</td></tr> <tr><td>8</td><td>0</td><td>V</td><td></td></tr> <tr><td>-</td><td>-</td><td>-</td><td>-</td></tr> </table> </div> </div> </div>	+	+	+	+	8	0	V		-	-	-	-	Max. Bus Voltage DC bus voltage limit for generating over-voltage error. <i>Standard value: 80 Volt for 48 V units</i>
+	+	+	+											
8	0	V												
-	-	-	-											
	<div style="border: 1px solid black; padding: 5px;"> <p>&lt;0&gt; Motor Temperature</p> <div style="display: flex; align-items: center;"> <div style="font-size: small; color: purple; margin-right: 5px;">DATA_ACQ</div> <div style="border: 1px solid black; padding: 2px;"> <table style="border-collapse: collapse; text-align: center;"> <tr><td>+</td><td>0</td><td>°C</td></tr> </table> </div> </div> </div>	+	0	°C	Motor Temperature Actual motor temperature in °C. [°F]= 1.8 x [°C] + 32									
+	0	°C												
	<div style="border: 1px solid black; padding: 5px;"> <p>&lt;1&gt; Rel/Aux Out</p> <ul style="list-style-type: none"> <li><input checked="" type="radio"/> RELAIS1</li> <li><input type="radio"/> RELAIS2</li> <li><input type="radio"/> -</li> <li><input checked="" type="radio"/> SYN_15V</li> <li><input type="radio"/> ENC_SINGLE</li> <li><input type="radio"/> -</li> <li><input type="radio"/> -</li> <li><input type="radio"/> PT100_ON</li> </ul> <p style="font-size: small; color: purple;">IN_OUT</p> </div>	Rel/Aux Out Internal control flags. <i>For MACCON tech assistance only.</i>												
DATA ACQUISITION	<div style="border: 1px solid black; padding: 5px;"> <p>&lt;0&gt; STR Error Flags (latched)</p> <ul style="list-style-type: none"> <li><input type="radio"/> OverTemp.Drive</li> <li><input type="radio"/> OverTemp.Motor</li> <li><input type="radio"/> EndatError</li> <li><input type="radio"/> CanTimeout</li> <li><input type="radio"/> CanMsgError</li> <li><input type="radio"/> Custom Err.1</li> <li><input type="radio"/> Custom Err.2</li> </ul> <p style="font-size: small; color: purple;">INTERNAL</p> </div>	STR Error Flags (latched) Displays µC error flags. <i>Used by MACCON tech support.</i>												

Tab. 7.14: Control windows in "DATA ACQUISITION" tab

**7.4.3.13 Control windows in "COMMAND INPUT SELECT" tab**

This section describes the command inputs used to set control mode and desired speed, position etc. Additional hardware enable by I/O signals can be required.

If you need additional parameters for your testing, refer to chap. 6.4.3, page 61, and chap. 6.4.5 on page 63.

COMMAND INPUT SELECT

Control window (in alphabetic order)	Explanation <i>Input values</i>
<div style="border: 1px solid black; padding: 5px;"> <p>&lt;0&gt; Brake Command</p> <p><input checked="" type="radio"/> Open Brake</p> <p><input type="radio"/> Close Brake</p> </div>	<p>Brake Command</p> <p>Allows manual brake control.</p> <p><i>Only for connected brake.</i></p>
<div style="border: 1px solid black; padding: 5px;"> <p>&lt;0&gt; Brake Mode</p> <p><input checked="" type="radio"/> SW / CAN</p> <p><input type="radio"/> Use Brake Command</p> <p><input type="radio"/> Close on Disable</p> </div>	<p>Brake Mode</p> <p>Brake mode used/set by</p> <ul style="list-style-type: none"> <li>– SW / CAN</li> <li>– “Brake Command” see above</li> <li>– “Disable” button of the GUI.</li> </ul> <p><i>“Disable” : brake will be engaged whenever drive is disabled</i></p>
<div style="border: 1px solid black; padding: 5px;"> <p>&lt;2&gt; CAN Current Limiting Command</p> <p>■■■0.0%</p> </div>	<p>CAN Current Limiting Command</p> <p>Actual CAN value for current limitation in %.</p> <p><i>Usage depends on CAN firmware (customer specific).</i></p>
<div style="border: 1px solid black; padding: 5px;"> <p>&lt;2&gt; CAN Enable Request</p> <p><input type="radio"/> Enable</p> </div>	<p>CAN Enable Request</p> <p>Actual status of CAN Enable request.</p> <p><i>Usage depends on CAN firmware (customer specific).</i></p>
<div style="border: 1px solid black; padding: 5px;"> <p>&lt;2&gt; Command Input</p> <p><input type="radio"/> PC</p> <p><input checked="" type="radio"/> Analog +/-10V</p> <p><input type="radio"/> Analog 0..+5V</p> <p><input type="radio"/> CAN</p> <p><input type="radio"/> HS_IN1(FWM)</p> </div>	<p>Command Input</p> <p>Select the desired command channel for operation.</p> <p>Use “Analog” when connecting an external function generator.</p>
<div style="border: 1px solid black; padding: 5px;"> <p>&lt;0&gt; Drive Mode</p> <p><input type="radio"/> Current</p> <p><input type="radio"/> Speed</p> <p><input checked="" type="radio"/> Position (Linear)</p> <p><input type="radio"/> Position (Circular)</p> <p><input type="radio"/> Sensorless (Speed)</p> <p><input type="radio"/> Sensorless (Current)</p> <p><input type="radio"/> U/V Current Cmds</p> </div>	<p>Drive Mode</p> <p>Select the required drive mode.</p>
<div style="border: 1px solid black; padding: 5px;"> <p>&lt;2&gt; DSP: Drive Mode</p> <p><input type="radio"/> Current</p> <p><input type="radio"/> Speed</p> <p><input checked="" type="radio"/> Position (Linear)</p> <p><input type="radio"/> Position (Circular)</p> <p><input type="radio"/> Sensorless (Speed)</p> <p><input type="radio"/> Sensorless (Current)</p> <p><input type="radio"/> U/V Current Cmds</p> </div>	<p>DSP Drive Mode</p> <p>Confirmation of the actually selected mode as set in the DSP.</p> <p><i>Used by MACCON tech support.</i></p>
	External Drive Mode Switch

COMMAND INPUT SELECT

COMMAND INPUT SELECT

Control window (in alphabetic order)	Explanation <i>Input values</i>
<p>&lt;0&gt; External Drive Mode Switch</p> <p><input checked="" type="radio"/> none used  <input type="radio"/> DIGIN1  <input type="radio"/> DIGIN2</p>	<p>To use digital input to change mode of operation.</p> <p><i>Usage depends on firmware (customer specific).</i></p>
<p>&lt;0&gt; External Enable Switch</p> <p><input type="radio"/> Testbox/RJ-12  <input checked="" type="radio"/> none used  <input type="radio"/> DIGIN1  <input type="radio"/> DIGIN2  <input type="radio"/> DIGIN3</p>	<p>External Enable Switch</p> <p>Selection of digital input as enable switch.</p>
<p>&lt;2&gt; Invert Command (IQ, Speed, U/V)</p> <p><input checked="" type="radio"/> NO  <input type="radio"/> YES</p>	<p>Invert Command (IQ, Speed, U/V)</p> <p>Inverts polarity of speed or current command.</p>
<p>&lt;2&gt; PC: Alt. Speed Command</p> <p>0.000 RPM [mm/s]</p>	<p>PC: Alt. Speed Command</p> <p>Second speed setpoint</p> <p>see "Use Alt. Command"</p> <p>Can be used for fast switching and generating a step behavior.</p>
<p>&lt;2&gt; PC: Current Command</p> <p>0.000%</p>	<p>PC: Current Command</p> <p>Current setpoint (Q vector) for operation by software.</p> <p><i>Used if "Command input" is set to "PC".</i></p>
<p>&lt;2&gt; PC: Current Command (D)</p> <p>0.000%</p>	<p>PC: Current Command (D)</p> <p>Current setpoint (D vector) for operation by software</p> <p><i>Used if "Command input" is set to "PC".</i></p>
<p>&lt;2&gt; PC: Speed Command</p> <p>0.000 RPM [mm/s]</p>	<p>PC: Speed Command</p> <p>Speed setpoint for operation by software</p> <p><i>Used if "Command input" is set to "PC".</i></p>
<p>&lt;2&gt; Speed Control: Actual Speed</p> <p>0.000 rpm [mm/s]</p>	<p>Speed Control: Actual Speed</p> <p>Actual speed as derived from active speed sensor position.</p>
<p>&lt;0&gt; Start-Up Enable State</p> <p><input checked="" type="radio"/> Disabled  <input type="radio"/> Enabled</p>	<p>Start-Up Enable State</p> <p>This allows the drive to auto-enable on power-up. This refers to software enabling.</p> <p>Additional hardware signals may be required.</p>
<p>&lt;2&gt; Use Alt. Command</p> <p><input type="radio"/> NO  <input checked="" type="radio"/> YES</p>	<p>Use Alt. Command</p> <p>Switches between the two setpoints.</p>

COMMAND INPUT SELECT

COMMAND INPUT SELECT

COMMAND INPUT SELECT	Control window (in alphabetic order)	Explanation <i>Input values</i>
	<div style="border: 1px solid black; padding: 5px;">                     &lt;2&gt; Use CAN Curr. Limiting Cmd.  <input type="radio"/> NO  <input checked="" type="radio"/> YES                 </div>	Use CAN Curr. Limiting Cmd.  Flag for using CAN value for current limitation.  <i>Used by MACCON tech support.</i>

Tab. 7.15: Control windows in "COMMAND INPUT SELECT" tab

7.4.3.14 Control windows in "ANALOG INPUT" tab

ANALOG INPUT	Control window (in alphabetic order)	Explanation <i>Input values</i>
	<div style="border: 1px solid black; padding: 5px;">                     &lt;1&gt; Analog Cmd Input 1                      IN_OUT                      - - - - - 0                 </div>	Analog Cmd Input 1  Output of D/A converter of analog input 1
	<div style="border: 1px solid black; padding: 5px;">                     &lt;1&gt; Analog Cmd Input 2                      IN_OUT                      + - - - - 1                 </div>	Analog Cmd Input 2  Output of D/A converter of analog input 2
	<div style="border: 1px solid black; padding: 5px;">                     &lt;1&gt; Analog Cmd Input Aux                      IN_OUT                      + - - - - 3                 </div>	Analog Cmd Input Aux  Output of D/A converter of analog input "AUX".
	<div style="border: 1px solid black; padding: 5px;">                     &lt;2&gt; Analog Cmd Lowpass, PT1                      CNTRL                      + +                      0                      - -                 </div>	Analog Cmd Lowpass, PT1  Lowpass setting for analog commands.
	<div style="border: 1px solid black; padding: 5px;">                     &lt;2&gt; Analog Cmd1 Adjusted                      CNTRL                      - - - 0.0032%                 </div>	Analog Cmd1 Adjusted  Scaled value of analog input 1.
	<div style="border: 1px solid black; padding: 5px;">                     &lt;2&gt; Analog Cmd1: Gain Adjust                      CNTRL                      + + + + +                      + - - - - 0.0000%                      - - - - -                 </div>	Analog Cmd1: Gain Adjust  Scaling for analog command 1.
ANALOG INPUT	<div style="border: 1px solid black; padding: 5px;">                     &lt;2&gt; Analog Cmd2 Adjusted                      CNTRL                      + - - - - 0.0064%                 </div>	Analog Cmd2 Adjusted  Scaling for analog command 2.
	<div style="border: 1px solid black; padding: 5px;">                     &lt;2&gt; Analog Cmd2: Gain Adjust                      CNTRL                      + + + + +                      + - - - - 0.0000%                      - - - - -                 </div>	Analog Cmd2: Gain Adjust  Scaling for analog command 2.



**ANALOG INPUT**

Control window (in alphabetic order)	Explanation <i>Input values</i>
	<p>Analog-In 1 Offset</p> <p>Offset setting for calibration of analog input 1</p> <p><i>Adjust to set "Analog Cmd Input 1" to zero at 0 V input voltage</i></p>
	<p>Analog-In 2 Offset</p> <p>Offset setting for calibration of analog input 2</p> <p><i>Adjust to set "Analog Cmd Input 2" to zero at 0 V input voltage</i></p>
	<p>Analog-In Aux Offset</p> <p>Offset setting for calibration of analog Aux input.</p> <p><i>Adjust to set "Analog Cmd AUX" to zero at 0 V input voltage</i></p>
	<p>Analog/PWM: Full Scale Current</p> <p>Set desired current command at maximum input voltage. Also used for digital (PWM) command input.</p>
	<p>Analog/PWM: Full Scale Speed</p> <p>Set desired current command at maximum input voltage. Also used for digital (PWM) command input.</p>
	<p>Invert Command (IQ, Speed, U/V)</p> <p>Inverts the command channel 1.</p>
	<p>Invert Command 2 (ID)</p> <p>Inverts the command channel 2.</p>
	<p>Speed Limit</p> <p>Overspeed protection. If exceeded, motor current will be gradually reduced</p>
	<p>Use ANAIN2 as ID Command</p> <p>Use analog input 2 to set D current.</p> <p>To be used in current control mode for manual field weakening operation.</p>

**ANALOG INPUT**

**ANALOG INPUT**

Tab. 7.16: Control windows in "ANALOG INPUT" tab

## 7.5 Operational tasks with SWM7 GUI (TBD)

Using the SWM7 software you can carry out

- Monitoring the drive and motor parameters (e.g. temperature, velocity, current)
- Setup the hardware configuration (motor, sensor, interfaces)
- Speed Control, see measuring window “Speed Control: Actual Speed” in “SPEED / CURRENT CONTROL” tab
- Current Control, see in control windows for “Current Control P gain”, “Current Control I gain”, “Current Control D gain” in “SPEED / CURRENT CONTROL” tab
- Phase Finding  
To detect initial commutation angle if no absolute position sensors (like hall sensors, resolvers, absolute encoders) are present.
- Field Weakening mode  
To set up field weakening to reach higher motor speeds with a given supply voltage.
- Setup and configuration of external interfaces (e.g. analog outputs, external enable inputs)
- Optimization of your application
- Troubleshooting and data acquisition for MACCON tech support.

Some parameters can only be set/adjusted while the

- drive is disabled (like sensor configuration), others can be adjusted
- motor is running (like controller gains).

You can use the “Disable” and “Enable” buttons to disable and enable the SWM7 drive.



Only professional personnel who have the relevant expertise are permitted to carry out online parameter settings for a drive that is running.

In case of errors, hardware problems or other service related questions contact MACCON tech support.



In this manual, only the default parameters (~ 270) of over 500 possible control windows are described.

Also, the arrangement of the SWM7 tabs and control windows depends on the project and may differ from this description.

### 7.5.1 Recommended sequence for operation (TBD)

This chap. contains information about the recommended sequence for operation. You can follow step by step this sequence or choose any specific operational step.

The following Tab. 7.8 allows quick access to the

- *Operational tasks* in the SWM7 tabs and
- *Details*, i.e. complete description of each control window.

Select the desired <chap.> or on <page>.

Step	SWM7 tab	Operational task		Description control windows	
		chap.	page	chap.	page
1	SYSTEM SETUP	7.5.1.1	116	7.4.3.10	101
2	DATA AQUISION	7.5.1.2	116	7.4.3.12	105
3	SENSORLESS CONTROL	7.5.1.3	118	7.4.3.2	79
4	SPEED / CURRENT CONTROL	7.5.1.4	118	7.4.3.8	93
5	MOTION SENSORS	7.4.3.9	97	7.4.3.9	97
6	MOTION SENSORS MONITORING	7.4.3.7	89	7.4.3.7	89
7	FIELD WEAKENING	7.5.1.7	120	7.4.3.3	81
9	PHASE FINDING	7.4.3.4	83	7.4.3.4	83
9	OFFSET	7.4.3.6	87	7.4.3.6	87
10	ANALOG INPUT	7.4.3.14	112	7.4.3.14	112
....	TBD				

For MACCON tech assistance:

SWM Status	7.5.1.5	119	7.4.3.11	102
CAN	7.5.1.6	120	7.4.3.5	85

**Tab. 7.17:** Sequence for operational tasks


**7.5.1.1 System setup**

This part displays the basic description for the used motor type. Using the SetUp tool you can check the current settings or adapt to a new HW.

Before setup check the present HW (motor data sheet, sensor type).

Recommended settings/checks:

- Motor Winding
- Motor Type
- Motor temp sensor type
- Motor Inductance
- Back EMF Const
- Pole Pairs
- Pole Pitch.



**7.5.1.2 Data Acquisition**

The tab “DATA ACQUISITION” is used for data collection and monitoring of important functions of the SWM7.

Different internal data, mainly concerning the power stage and processor status, is summarized in this section. Limitations for power stage bus voltage and current can be set. The state of digital I/O as well as processor status flags can be monitored.

The displayed values

- Temperature
- Current and
- Voltages

should be monitored regularly during operation.

Recommended control windows:

The screenshot displays a grid of parameter configuration boxes. Each box contains a title, a category label (e.g., DATA\_ACO, SYS, INTERNAL, DEBUG), and a numerical value with up/down arrows for adjustment.

- Bus Voltage** (DATA\_ACO): +110.2V
- Max. Bus Voltage** (SYS): 180V
- Bus Current** (DATA\_ACO): -110.0A
- Bus Current Offset** (SYS): +10.0A
- Drive Temperature** (DATA\_ACO): +40°C
- Motor Temperature** (DATA\_ACO): +110°C
- Bus Voltage ADC Range** (SYS): 1186V
- Bus Current ADC Range** (SYS): 1190A
- Current ADC Range (peak)** (SYS): 35.8A
- Bus Current Limit** (SYS): 110.0A (0=OFF)
- ANAOUT1 Gain** (DEBUG): 1.000 Volt.Range
- ANAOUT1 Offset** (DEBUG): 0.0 mV
- FPGA Status Flags** (INTERNAL):
  - Enabled
  - EnabDspUser
  - EnabStrUser
  - EnabSwitch
  - DspEnabSW
  - StrEnabSW
  - DspSWErr
  - StrSWErr
  - OCurr1
  - OCurr2
  - UndVolt
  - DSP Timeout
  - STR Timeout
- FPGA Status Flags 2** (INTERNAL):
  - Brake On
- DSP Error Flags (latched)** (INTERNAL):
  - OverCurrent
  - I2t-Warning
  - I2t-Error
  - OverVoltage
  - .
  - .
  - .
  - .
  - OverCurrent HW
  - OverCurrent2 HW
  - UnderVolt int.
- STR Error Flags (latched)** (INTERNAL):
  - OverTemp.Drive
  - OverTemp.Motor
  - EndatError
  - CanTimeout
  - CanMsgError
  - Custom Err.1
  - Custom Err.2

**Optional:**


- Select the assignment of signals to analog outputs ANAOUT1...ANAOUT3 (3 analogue outputs for SWM7, 6 analogue outputs for SWM7S)

### 7.5.1.3 Sensorless control

For sensorless motor control, the relevant settings can be made here.

In this tab. is possible the sensorless control using

- Speed input = “PC: Speed Command” and
- Current input = “Start Current (DC)”.




Usually you receive a customized and validated parameter set for your sensorless application.

### 7.5.1.4 Speed / Current Control **TBD**


In this section the control parameters for current and speed loop are adjusted:

Current Control		Speed Control	
Field Weakening Mode	Auto field weakening mode selection	Speed Control: D gain	Set D gain only if fast load changes are expected
Max. Reactive Current	Current limitation setting (D vector)	Speed Control: KVFR	Speed control feed forward for faster reaction of current controller
Max. Current Angle	only relevant for auto field weakening mode		
Speed Limit	Speed limit in current control mode		
Estimated Back EMF	Back EMF as estimated by operation point and motor data		
Current Command Q	Display of actual current loop command (Q vector)		
Current Command D	Display of actual current loop command (D vector)		




### 7.5.1.5 SWM status

Firmware versions and internal status flags are displayed here. This information may be needed if queried by MACCON tech support.



**7.5.1.6 CAN**


Will be available in a next version – used for MACCON tech support.



**7.5.1.7 Field weakening**

The SWM7 includes two field-weakening modes. Based on a set of motor parameters, the measured bus voltage and engine speed and the commanded current value, the optimum motor currents are determined. The current command can also be the output of the speed controller.

The choice is made with the parameter "Field Weakening Mode", see below:



**Figure 7.7:** Field Weakening Mode

- ➔ **IQ=const**  
In this mode, the current setpoint is understood as active current setting (IQ). Each the operating point of the algorithm adds an additional reactive current (ID) was added.
- ➔ **Imot=const**  
In this mode, the current setpoint is the total engine current. Depending on the operating point the algorithm divides this total current in an active current component (IQ) and a reactive current component (ID).

For controlling and monitoring field weakening mode by setup software it is useful to add the following parameters:

1. Active Speed Sensor ➔ Rotatory speed
2. Command Inputs ➔ PC Current Command
3. Command Inputs ➔ PC Current Command D

**Operating principle**

Shown by a 1-phase diagram with rotor vectors, see Fig. 7.8.






Figure 7.8: Rotor vectors (voltage and current)

Setting only an effective current vector  $I_Q$ , the reaction is an output voltage of  $U_1$ . Should this voltage get higher than the bus voltage, no further current can be supplied and the motor speed reaches its limit.

Adding a reactive current  $I_D$ , the inductive loss of voltage  $U_{dD}$  leads to the output voltage  $U_2$  which is lower. With this effect the motor speed can be further increased.

For automatic monitoring of additional reactive current in the "Field Weakening Mode" two algorithms are implemented.

**$I_Q = \text{const.}$**   $I_Q$  is defined by the current setpoint,  $I_D$  is zero at the beginning. When the bus voltage (back EMF limit) is reached additional reactive current  $I_D$  is applied; the absolute value of the effective current stays unchanged.

This results in nearly constant torque, the motor current gets higher than commanded.

**$I_{\text{mot}} = \text{const.}$**   $I_Q$  is defined by the current setpoint,  $I_D$  is zero at the beginning. When the bus voltage (back EMF limit) is reached additional reactive current  $I_D$  is applied; the absolute value of the effective current is reduced. Hereby, the torque is reduced, the motor current stays at the commanded value.

Manual control of field weakening operation can be achieved by the following procedure:

- ⇒ Increase *Q current* until maximum speed is reached.
- ⇒ Start increasing *D current* and watch increasing speed.

Generally,  $I_Q$  component can be reduced proportionally to the speed increase as this is equal to the reduced torque which is available.

## 7.6 Optimization

Result of an optimization, see Fig. 7.9 below:

Optimum PID Coefficients - P=4, I=0.001, D= 4




Figure 7.9: Optimum PID coefficients





Figure 7.10: PID Control system (result)

### 7.7 Save Settings

For details see in chap. 6.4.1.

## 7.8 Error Messages

The message text, see Tab. 7.10, will be displayed in the status line of the SWM7 GUI in red:



The codes for the errors **F0**, **F1** and **F2**, see error matrix below, can be read out on the X2 Signal Connector

<b>F0</b>	X2-9	DIGOUT1
<b>F1</b>	X2-10	DIGOUT2
<b>F2</b>	X2-11	DIGOUT3

### 7.8.1 Error matrix

The following table shows different error numbers F0 to F7 and the message text:

F0 DIGOUT1	F1 DIGOUT2	F2 DIGOUT3	No.	Message text
0	0	0	F0	No error
0	0	L	F1	Over Voltage
0	L	0	F2	Under Voltage
0	L	L	F3	Over Current
L	0	0	F4	Over temperature heat sink
L	0	L	F5	Error on resolver or option card
L	L	0	F6	I*t warning
L	L	L	F7	I*t limiting

Tab. 7.18: Error matrix

## 7.9 Trouble Shooting



MACCON tech support can give you further assistance with problems.

Fault	Possible causes	Measures
HMI message: Communication fault	Wrong cable used	Use null-modem cable
	Cable plugged into wrong position on servo controller or PC	Plug cable into the correct sockets on the servo controller and PC
	Wrong PC interface selected	Select correct COM port (see chap. 6.3.1.2.1)
Motor does not rotate	Servo controller not enabled apply	ENABLE signal
	Software enable not set	Set software enable
	Break in setpoint cable	Check setpoint cable
	Motor phases swapped	Correct motor phase sequence
	Brake not released	Check brake control
	Drive is mechanically blocked	Check mechanism
	Motor pole no. set incorrectly	Set motor pole no.
Feedback set up incorrectly	Set up feedback correctly	

Fault	Possible causes	Measures
Motor oscillates	Feedback cable shielding broken	Replace feedback cable
	AGND not wired up	Join AGND to GND
Drive reports following error	I <sub>rms</sub> or I <sub>peak</sub> set too low	Increase I <sub>rms</sub> or I <sub>peak</sub> (keep within motor ratings!)
Motor overheating	Acceleration / deceleration ramp is too long	Shorten ramp ±
	I <sub>rms</sub> /I <sub>peak</sub> is set too high	Reduce I <sub>rms</sub> /I <sub>peak</sub>
Axis drifts at setpoint = 0 V	Offset not correctly adjusted for analog setpoint provision	Adjust offset (analog I/O)
	AGND not joined to the controller GND of the controls	Join AGND and controller GND

**Tab. 7.19:** Trouble Shooting for different faults (examples)





## 8 Glossary

<b>A</b>	AC	Alternating current
	AC	Air-cooled
	AGND	Analogue ground
	ARINC 825	Communication protocol no. 825 (CAN data bus) designed by Aeronautical Radio Incorporated (Annapolis, Maryland)
<b>B</b>	BiSS	Bidirectional Serial Synchron Open Source interface
	Brake circuit	Converts superfluous energy fed back by the motor during braking (regenerated energy) into heat.
	BL	Brushless (also abbreviated DC3)
	BR	Plug-on jumper
<b>C</b>	CAN	Control Area Network, an industrial field bus standard
	Clock	Clock signal
	Common-mode voltage	The maximum amplitude of a disturbance (on both inputs) which a differential input can eliminate
	Counts	Internal count pulses
	CPLD	Complex Programmable Logic Device
	Current controller	Regulates the motor phase currents
	CW	Clockwise, positive limit switch
	CCW	Counter clockwise, negative limit switch
	CE	Certified Europa ( Communauté Européenne)
<b>D</b>	Kd, D gain	Derivative gain
	D/A converter	Digital to analog converter
	DC bus link	Rectified and smoothed power voltage
	DC1	Brush, DC motor (2 connections)
	DC3	Brushless, 3 phase synchronous motor
	DGND	Digital ground
	DC	Direct current
	DC-Bus	Main power supply voltage, DC
	Disable	Removal of the ENABLE signal
	DSP	Digital signal processor
	DT	3-Phase transformer
	<b>E</b>	Earth short
Enable		Enable signal for the servo controller, hardware ENABLE signal which can be applied to X2 (X1-1 optional)
EMF		Electromagnetic field
EMC		Electromagnetic compatibility
EN		European standard
ET		Single phase transformer (usually from 230V/50 Hz, 110V/60 Hz)
ENABLE		ENABLE signal for the servo controller consult chap. 5.8, page 41 according voltage level
<b>F</b>	Field bus	Interface CAN

	Final speed (limit speed)	Maximum value for the speed normalization at $\pm 10V$
	FPGA	Field Programmable Gate Array
<b>G</b>	GRAY-code	Special format for representing binary numbers
	GUI	Graphical User Interface
<b>H</b>	Holding brake	Holding brake in the motor, that can only be used when the motor is at standstill
	Hall, HE, H-E	Hall-effect sensor, magnetic position sensor
<b>I</b>	Ki, I gain	Integral gain
	I <sub>t</sub> threshold	Monitoring of the rms current that is actually required
	IEC	International Electrotechnical Commission
	Input drift	Temperature and age-dependent alteration of an analog input
	Incremental encoder interface	Position signaling by 2 signals with 90° phase difference (i.e. in quadrature), is not an absolute position output
	I <sub>peak</sub> , peak current	Effective value of the peak current
	I <sub>rms</sub> , effective current	The rms value of the continuous current.
<b>K</b>	K <sub>p</sub> , P-gain	Proportional gain of a control loop
	KVFR	Velocity Feed forward Ratio
<b>L</b>	LB	Solder jumper/bridge
	LED	Light emitting diode
	Limit speed (final speed)	Maximum value for speed normalization at $\pm 10$
	Limit switch	Switch limiting the traverse path of the machine; implemented as n. c. (break) contact
	LWM	Sine Wave Monitored servo controller for linear motors, e.g. LWM7
<b>M</b>	Machine	The complete assembly of all connected parts or devices, of which at least one is movable.
	MAF	Moving Average Filter
	MH	Motor Housing
	Motion block	Data packet with all the position control parameters which are required for a motion task
	MT	Fuse, medium response
	Multi-axis system	Machine with several independently driven axes
<b>N</b>	Natural convection	Free movement of air for cooling
<b>O</b>	optocoupler	Optical connection between two electrically independent systems
	Output	Speed setpoint
<b>P</b>	P gain	Proportional gain of a control loop



	PE	Protective earth
	P-controller	Control loop with purely proportional behavior
	Phase shift	Compensation for the lag between the electromagnetic and magnetic fields in the motor
	PI-controller	Control loop with proportional and integral behavior
	Position controller	Regulates the difference between the position setpoint and the actual position to
	Potential isolation	Electrically decoupled, electrical isolation
	Power contactor	System protection device with phase monitoring
	PSU	Power Supply Unit
	Pulse power of the brake circuit	Maximum power which can be dissipated in the brake circuit
	PWRGND	Power ground
	PWM	Pulse-width modulation
<b>R</b>	Reset	New start of a system
	Resolver/digital converter	Conversion of the analog resolver signals into digital information
	RFR	<b>Ready for Final Review</b>
	Reversing mode	Operation with a periodic change of direction
	Ring core	Ferrite rings for interference suppression
	RMS, r.m.s.	Root mean square
	ROD-interface	Read-Out Driver interface (Incremental position output)
	RP	Potentiometer
<b>S</b>	Servo controller	Control device for regulating the speed, torque and position of a servomotor
	SGND	Signal ground
	Setpoint ramps	Limits for the rate of change of the speed setpoint
	Short-circuit	In this manual: electrically conductive connection between two phases
	Speed controller	Regulates the difference between the speed setpoint and the actual value to Output: current setpoint
	SSI interface	Cyclically absolute, serial position output
	ST	Connector
	ST2	Stepper motor, 2-phase
	ST3	Stepper motor, 3-phase
	SWM	Sine Wave Monitored servo controller for servo motors e.g. SWM7
	Supply filter	Device to divert interference on the power supply cables to PET
<b>T</b>	Tachometer voltage	Voltage proportional to the actual speed
	TB	Test Box (optional)
	TBD	To be defined (editorial notes for PRELIMINARY issue)
	Thermal control	Temperature-sensitive device built into the motor winding (usually a PTC)
	T <sub>n</sub> , I-integration time	Integral component of a control loop
<b>W</b>	WC	Water-cooled

<b>Z</b>	Zero pulse	Output once per turn from incremental encoder, used to zero the machine
<b>μ</b>	μC	Microcontroller, MCU



---

## 9 Index

|

## 10 EMC Recommendations

To meet the requirements of the EMC regarding emission and noise immunity, internal filter measures are implemented in the SWM7S servo controllers.

In addition, external filtering and shielding measures are recommended. These measures must comply with to the overall concept of your design and machine.

### 10.1 External filtering measures

The SWM7S servo controller not be operated directly from the mains supply. The power supply for the device is realized via an appropriate transformer, rectifier and a filter unit. Despite good damping characteristics of transformers with respect to line-conducted interference, we recommend the use of input filters in the primary supply of the transformer. A selection of different types of filters can be found in Tab. 10.1.

#### 10.1.1 AC Mains filter

Manufacturer: Fa. Schaffner

Filter type	Input	Nominal current	Power dissipation	Weight	Used for SWM
FN351-5/29	3 x 400 V, 3 Phases	5 A	6 W	1.1 kg	48/12.5 – 25
FN351-8/29	3 x 400 V, 3 Phases	8 A	7 W	0.8 kg	48/50/100
FN351-16/29	3 x 400 V, 3 Phases	16 A	8 W	1.3 kg	48/50/100
FN351-25/33	3 x 400 V, 3 Phases	25 A	8 W	1.4 kg	300/25
FN350-8/29	1 x 250 V	8 A	5.2 W	0.7 kg	
FN350-12/29	1 x 250 V	12 A	6.1 W	0.7 kg	

**Tab. 10.1:** AC Mains filter (before the transformer)

#### 10.1.2 DC Mains filter


For details refer to **Tab. 10.2**.

### 10.2 Additional filtering measures

At the motor output of the servo controller, connected in series with the motor connection cables, motor chokes may be used (near the servo controller needs a common ground used for SWM7S only).

These filters are special RF filters to be installed near the servo controller and ask here for a common ground reference (Chassis housing to PE).

This type of filter is particularly recommended for long motor cables ( $\geq 25$  m). MACCON GmbH provides the filter types acc. Tab. 10.2.



**Figure 10.1:** DC mains filter (SWM7S input filter) technology acc. chap. 10.1.2

### 10.3 Motor chokes

The following motor chokes are available as standard:

Type	Inductance	Nominal current	Dimension diameter x height	Weight	Remarks
L100/3K	1 mH	3 A	45 x 30 mm	0.25 kg	Toroid core; fit for PWM; f <sub>max</sub> 50 kHz
L020/6K	0.2 mH	6 A	60 x 40 mm	0.6 kg	
L050/8K	0.12 mH	8 A	60 x 41 mm	0.6 kg	
L012/20k	9.12 mH	20 A	60 x 41 mm	0.6 kg	

**Tab. 10.2:** Motor chokes (optional)



In case of chokes and filters related questions contact MACCON tech support or phone +49 89 651220-0





Figure 10.2: SWM HV (High voltage) Controller Supply

## 10.4 Mounting Instructions

- The installation cabinet to be made out of metallic, good conductive materials and to interconnect via low resistance and high surface with all chassis elements and the earthing point or shield equalizer. This equalizer must provide at least 6 mm<sup>2</sup> of cross section.
- all connection cables from and to the SWM7S servo controller have to be shielded
- To avoid joined lines signal and load cables have to be arranged separately. We recommend a minimum distance of 25 cm.
- Both ends of the load cable shields have to be connected via low resistance and high surface to the chassis earthing point or the shield equalizer of the cabinet. Signal cable shields to be connected within same manner at one end to the shield
- Shields need to be intact, providing a high overlap rate throughout the cables to the shield equalizer (or earthing point of the cabinet).

- In case there is no shielding bus existing, each servo controller has to be connected from the ground screw to the central earthing point of the device by an equalizer (minimum 2.5 mm<sup>2</sup> cross section). The shield layers have to be connected to the SWM ground screw.
- The line filters to be installed at the cabinet entry point with high surface connection (low resistance) to the chassis of the cabinet.
- Wiring is not to be laid freely in the cabinet, but should rather lead as tightly as possible to the electrically grounded cabinet frame.
- When using a shielding bus attaching the shield layer on the servo controller is not necessary. This requires a short cable length ( $\leq 20$  cm) between grounding bus and servo controller.
- All outgoing shield layers have to connect to the SWM shielding screw with the greatest possible surface.
- the motor/sensor connection to the shielding of the signal and load cable is ensured by appropriate connectors or directly on the case.
- To prevent potential differences between motor and controller (mainly in the case of long cables) it is necessary to ensure an equipotential bonding for all components.



Remove outer insulation and screen at end of cable over required length.

Secure wires with cable strap.

Remove outer insulation over a length of about 30 mm without damaging screen. Fix cable with an earthing clip.

Connect this clip via copper braid to the closely situated earthing screw on the SWM7S housing.

**Figure 10.3:** SWM7S cable shield



In case of EMC related questions contact MACCON tech support or phone +49 89 651220-0